



FILE NO.

SERVICE MANUAL Multimedia Projector

Model No. PLV-Z2

(U.S.A., Canada, Europe Asia, Africa, U.K.)





If the Original Version Service Manual Chassis No. does not match the unit's, additional Service Literature is required. You must refer to "Notices" to the Original Service Manual prior to servicing the unit.



CONTENTS	
	Pages
TECHNICAL SPECIFICATIONS	2
SAFETY INSTRUCTIONS	3
LAMP REPLACEMENT	
INDICATORS AND PROJECTOR CONDITION	6
WARNING INDICATOR	
CLEANING	
DIMENSIONS	
PROTECTIONS	
MECHANICAL DISASSEMBLIES	
OPTICAL PARTS DISASSEMBLIES	
LCD PANEL/PRISM ASS'Y REPLACEMENT	
ADJUSTMENT AFTER PARTS REPLACEMENT	22
OPTICAL ADJUSTMENT	
ELECTRICAL ADJUSTMENT	
TEST POINTS AND LOCATIONS	
LOCATIONS OF FAN AND BOARD	
CIRCUIT BLOCK DIAGRAM	
POWER SUPPLY LINES	
POWER SOURCE LINES (IC)	
TROUBLESHOOTING	
IC BLOCK DIAGRAMS	
ELECTRICAL PARTS LIST	
MECHANICAL (OPTICAL) PARTS LIST & ACCESSORIES	58 - 63
DIAGRAMS & DRAWINGS	
PARTS DESCRIPTION AND READING IN SCHEMATIC DIAGRAM -	A2
SCHEMATIC DIAGRAMS	
PRINTED WIRING BOARD DIAGRAMS	
PIN DESCRIPTION OF DIODE, TRANSISTOR AND IC	A11

Technical Specifications

Projector Type	Multimedia Projector					
Dimensions (W x H x D)	14.13" x 3.82" x 10.79" (359mm x 97mm x 274mm) (not including raised portions)					
Net Weight	9.0 lbs (4.1 kg)					
LCD Panel System	0.7" wide TFT Active Matrix type, 3 panels					
Panel Resolution	1280 x 720 dots					
Number of Pixels	2,764,800 (1280 x 720 x 3 panels)					
Color System	PAL, SECAM, NTSC, NTSC4.43, PAL-M, and PAL-N					
High Definition TV Signal	480i, 480p, 575i, 575p, 720p, 1035i, and 1080i					
Scanning Frequency	H-sync. 15 ~ 80 KHz, V-sync. 50 ~ 100 Hz					
Projection Image size (Diagonal)	Adjustable from 31" to 200"					
Projection Lens	F 2.04 ~ 2.54 lens with f 21.5 mm ~ 27.7 mm with manual zoom and focus					
Throw Distance	3.9' ~ 20.0' (1.2 m ~ 6.1 m)					
Projection Lamp	135 W					
Video Input Jacks	RCA Type x 4 (Video, Y, Pb/Cb, Pr/Cr) and Mini DIN 4 pin x 1 (S-Video)					
Computer/Video Input Terminal	DVI-I Terminal (Digital/Analog) (HDCP compatible)					
Service Port Connector	Mini DIN 8 pin x 1					
Feet Adjustment	0° to 11.8°					
Voltage and	AC 100 ~ 120 V (2.4 A Max. Ampere), 50 / 60 Hz (The U.S.A. and Canada)					
Power Consumption	AC 200 ~ 240 V (1.3 A Max. Ampere), 50 / 60 Hz (Continental Europe and The U.K.)					
Operating Temperature	41 °F ~ 95 °F (5 °C ~ 35 °C)					
Storage Temperature	14 °F ~ 140 °F (-10 °C ~ 60 °C)					
Remote Control	Power Source : AA, UM3 or R06 Type x 2 Operating Range : 16.4' (5m) / ±30° Dimensions : 1.85" x 1.18" x 6.26" (47mm x 30mm x 159mm) Net Weight : 4.4oz (125g) (including batteries)					
Accessories	Owner's Manual AC Power Cord Remote Control and Batteries Video Cable					

- The specifications are subject to change without notice.
- LCD panels are manufactured to the highest possible standards. Even though 99.99% of the pixels are effective, a tiny fraction of the pixels (0.01% or less) may be ineffective by the characteristics of the LCD panels.

■ Safety Instructions

■ SAFETY PRECAUTIONS

WARNING:

The chassis of this projector is isolated (COLD) from AC line by using the converter transformer. Primary side of the converter and lamp power supply unit circuit is connected to the AC line and it is hot, which hot circuit is identified with the line () in the schematic diagram. For continued product safety and protection of personnel injury, servicing should be made with qualified personnel.

The following precautions must be observed.

- 1: An isolation transformer should be connected in the power line between the projector and the AC line before any service is performed on the projector.
- 2: Comply with all caution and safety-related notes provided on the cabinet back, cabinet bottom, inside the cabinet or on the chassis.
- **3:** When replacing a chassis in the cabinet, always be certain that all the protective devices are installed properly, such as, control knobs, adjustment covers or shields, barriers, etc.

DO NOT OPERATE THIS PROJECTOR WITHOUT THE PROTECTIVE SHIELD IN POSITION AND PROPERLY SECURED.

4: Before replacing the cabinet cover, thoroughly inspect the inside of the cabinet to see that no stray parts or tools have been left inside.

Before returning any projector to the customer, the service personnel must be sure it is completely safe to operate without danger of electric shock.

■ PRODUCT SAFETY NOTICE

Product safety should be considered when a component replacement is made in any area of the projector. Components indicated by mark \triangle in the parts list and the schematic diagram designate components in which safety can be of special significance. It is, therefore, particularly recommended that the replacement of the parts must be made by exactly the same parts.

■ SERVICE PERSONNEL WARNING

Eye damage may result from directly viewing the light produced by the Lamp used in this equipment. Always turn off Lamp before opening cover. The Ultraviolet radiation eye protection is required during this servicing.


Never turn the power on without the lamp to avoid electric-shock or damage of the devices since the stabilizer generates high voltages(20~25kV) at its starts.

Since the lamp is very high temperature during units operation. Replacement of the lamp should be done at least 45 minutes after the power has been turned off, to allow the lamp cool-off.

■ Lamp Replacement

■ Lamp Replacement

When the life of the projection lamp of this projector draws to an end, the LAMP REPLACE indicator lights yellow. If this indicator lights yellow, replace the lamp with a new one promptly.





CAUTION


Allow a projector to cool, for at least 45 minutes before you open the Lamp cover. The inside of the projector can become very hot.

↑ CAUTION

For continued safety, replace with a lamp of the same type. Do not drop a lamp or touch a glass bulb! The glass can shatter and may cause injury.

Follow these steps to replace the lamp.

- Turn off the projector and disconnect the AC plug. Allow the projector to cool for at least 45 minutes.
- **2** Turn over the projector. Loosen the screw with a screwdriver, and remove the lamp cover.
- 3 Loosen 2 screws of the lamp with a screwdriver and pull out the lamp by grasping the handle.
- Replace the lamp with a new one and tighten the 2 screws back into position. Make sure that the lamp is set properly. Replace the lamp cover and tighten the screw.
- **5** Connect the AC power cord to the projector and turn on the projector.
- 6 Reset the Lamp replace counter.
 See "Lamp Replace Counter" on the next page.



ORDER REPLACEMENT LAMP

Replacement lamp can be ordered through your dealer. When ordering a projection lamp, give the following information to the dealer.

Model No. of your projector : PLV-Z2

Replacement Lamp Type No. : POA-LMP69


(Service Parts No. 610 309 7589)

■ Lamp Replacement Counter

Be sure to reset the lamp replace counter after the lamp is replaced. When the lamp replace counter is reset, the LAMP REPLACE indicator stops lighting.

- 1 Turn the projector on, press the MENU button, and the On-Screen Menu will appear. Select the Setting Menu with the Point Up/Down button and press the Point Right button to enter the sub-menu.
- 2 Select the Lamp counter reset item and then press the SELECT button. The message "Lamp replace counter Reset?" is displayed. Choose [Yes] and then press the SELECT button.
- Another confirmation dialog box appears and choose [Yes] to reset the Lamp replace counter.

Lamp counter reset



NOTE

• Do not reset the Lamp replace counter without implementation of lamp replacement. Be sure to reset the Lamp replace counter only after replacing the lamp.

How to check lamp used time

The LAMP REPLACE indicator will light when the total lamp used time reaches 3,000 hours. This is to indicate that lamp replacement is required.

The total lamp used time is calculated by using the below expression;


Total lamp used time = \mathbf{T} eco + \mathbf{T} normal x (1.5)

Teco: used time in the Eco mode
Tnormal: used time in the Eco mode

You can check the lamp replace counter following to below procedure.

1 Press and hold the **POWER ON-OFF** button on the projector or the remote control unit for more than 20 seconds.

2 The projector used time and lamp used time will be displayed on the screen briefly.





LAMP HANDLING PRECAUTIONS

This projector uses a high-pressure lamp which must be handled carefully and properly. Improper handling may result in accidents, injury, or create a fire hazard.

- Lamp lifetime may differ from lamp to lamp and according to the environment of use. There is no guarantee of the same lifetime for each lamp. Some lamps may fail or terminate their lifetime in a shorter period of time than other similar lamps.
- If the projector indicates that the lamp should be replaced, i.e., if the LAMP REPLACE indicator lights up, replace the lamp with a new one IMMEDIATELY after the projector has cooled down.
 (Follow carefully the instructions in the Lamp Replacement section of this manual.) Continuous use of the lamp with the LAMP REPLACE indicator lighted may increase the risk of lamp explosion.
- A Lamp may explode as a result of vibration, shock or degradation as a result of hours of use as its
 lifetime draws to an end. Risk of explosion may differ according to the environment or conditions in
 which the projector and lamp are being used.

IF A LAMP EXPLODES, THE FOLLOWING SAFETY PRECAUTIONS SHOULD BE TAKEN.

If a lamp explodes, disconnect the projector's AC plug from the AC outlet immediately. Contact an authorized service station for a checkup of the unit and replacement of the lamp. Additionally, check carefully to ensure that there are no broken shards or pieces of glass around the projector or coming out from the cooling air circulation holes. Any broken shards found should be cleaned up carefully. No one should check the inside of the projector except those who are authorized trained technicians and who are familiar with projector service. Inappropriate attempts to service the unit by anyone, especially those who are not appropriately trained to do so, may result in an accident or injury caused by pieces of broken glass.

■ Indicators and Projector Condition

■ Indicators and Projector Condition

Check the Indicators for projector condition.

Indicators								
POWER red/green	WARNING red	LAMP REPLACE yellow	Projector Condition					
•	•	•	The Main On/Off switch is off or the AC power cord is unplugged.					
	•	*	The projector is preparing for stand-by and the front cover is closed. Or the projection lamp is being cooled down. The projector cannot be turned on until cooling is completed.					
	•	*	The projector is ready to be turned on with the POWER ON-OFF button.					
	•	*	The projector is operating normally.					
	•	*	The projector is in the Power management mode.					
		*	The temperature inside the projector is abnormally high. The projector can not be turned on. When the projector is cooled down enough and the temperature returns to normal, the POWER indicator lights red and the projector can be turned on. (The WARNING . indicator keeps flashing.) Chec and clean the Air filter.					
	NI.	*	The projector has been cooled down enough and the temperature returns to normal. When turning on the projector, the WARNING indicator stops flashing. Check and clean the air filter.					
•	0	*	The projector detects an abnormal condition and cannot be turned on. Unplug the AC power cord and plug it again to turn on the projector. If the projector is turned off again, disconnect the AC power cord and contact the dealer or the service center for service and checkup. Do not leave the projector on. It may cause electric shock or a fire hazard.					

^{••••} lights green. •••• flashes green. •••• lights red. •••• flashes red.

^{*}When the life of the projection lamp draws to an end, the LAMP REPLACE indicator lights yellow. When this indicator lights yellow, replace the projection lamp with a new one promptly. Reset the Lamp replace counter after replacement of the lamp.

■ Warning Indicator

■ Warning Indicator

The WARNING indicator shows the state of the function which protects the projector. Check the state of the WARNING indicator and the POWER indicator to take proper maintenance.

The projector is shut down and the WARNING indicator is flashing red

When the temperature inside the projector exceeds the normal temperature, the projector is automatically shut down to protect the inside of the projector. The POWER indicator is flashing and the projector is being cooled down. When the temperature inside the projector returns to normal, the POWER indicator lights red and the projector can be turned on.


NOTE

 After the temperature inside the projector returns to normal, the WARNING indicator still continues to flash. When the projector is turned on again, the WARNING indicator stops flashing.

Then check the items below.

- ✓ Did you provide appropriate space for the projector to be ventilated? Check the installing condition to see if ventilation slots are not blocked.
- ✓ Is the projector not installed near the ventilation duct of air-conditioning equipment which may be hot? Install the projector away from the ventilation duct of air-conditioning equipment.
- ✓ Is the air filter clean? Clean the air filter or replace it with a new one.

TOP CONTROL




The projector is shut down and the WARNING indicator lights red

When the projector detects an abnormal condition, it is automatically shut down to protect the inside and the WARNING indicator lights red. In this case, disconnect the AC power cord and reconnect it, and then turn the projector on once again for check. If the projector is turned off again and the WARNING indicator lights red, disconnect the AC power cord and contact the service station for check and repair.

CAUTION

DO NOT LEAVE THE PROJECTOR WITH THE AC POWER CORD CONNECTED UNDER THE ABNORMAL CONDITION. IT MAY RESULT IN FIRE OR ELECTRIC SHOCK.

TOP CONTROL



■ Cleaning the Air Filter

The air filter prevents dust from accumulating on the surface of the optical elements inside the projector. Should the air filter become clogged with dust particles, it will reduce cooling fans' effectiveness and may result in internal heat build up and adversely affect the life of the projector. Clean the air filter following the steps below.

- **1** Turn off the projector and disconnect the AC power cord from the AC outlet.
- Turn over the projector and remove the air filter by pulling the latches on both edges upward.
- Remove dust and dirt with a soft brush. Be careful not to damage the air filter and do not clean the air filter with water. When there is much dust and dirt on the air filter, replace it with a new one. (See below for replacing the air filter.)
- Put the air filter back into position. Make sure that the air filter is properly and fully inserted.



CAUTION


Do not operate the projector with the air filter removed. Dust may accumulate on the LCD panel and the projection mirror degrading picture quality.

Do not put small parts into the air intake vents. It may result in malfunction of the projector.



We recommend avoiding dusty/smoky environments when operating the projector. When using under dusty or smoky conditions, dust may accumulate on a lens, LCD panels, or optical elements inside the projector. This condition may degrade the quality of a projected image.

When the above symptoms are noticed, contact your authorized dealer or service station for proper cleaning.



■ Replacing the Air Filter


When there is much dust and dirt on the air filter, replace it with a new one following the steps below.

- 1 After removing the air filter from the projector as described above, remove the replacement filter from the holder.
- **2** Holds the air filter with both hands, and remove the replacement filter by pulling it up.
- 3 Install a new replacement filter and put the air filter back into the projector.

ORDER REPLACEMENT FILTER

Replacement filter can be ordered through your dealer or service station.

Replacement Filter Part No.: 610 312 0249



■ Cleaning the Projection Lens


Follow these steps to clean the projection lens.


- Disconnect the AC power cord before cleaning.
- 2 Softly wipe the projection lens with a cleaning cloth that contains a small amount of non-abrasive camera lens cleaner, or use lens cleaning paper or a commercially available air blower to clean the lens. Avoid using an excessive amount of cleaner. Abrasive cleaners, solvents, or other harsh chemicals might scratch the surface.
- **Q** When the projector is not in use, replace the lens cover.



Follow these steps to clean the projector cabinet.

- 1 Disconnect the AC power cord before cleaning.
- 2 Softly wipe the projector body with a soft, dry cleaning cloth. When it is heavily soiled, use a small amount of mild detergent and finish with a soft, dry cleaning cloth. Avoid using an excessive amount of cleaner. Abrasive cleaners, solvents, or other harsh chemicals might scratch the surface.
- When the projector is not in use, put the projector in the carrying case to protect it from dust and scratches.







■ Dimensions


■ Dimensions


Unit: inch (mm)



11.8° (Max.)







Protections

This projector is equipped with the following protections to operate in safety. If the abnormality occurs inside the projector, it will turn off the projector by operating one of the following protections.


■ FUSE FOR CIRCUIT PROTECTION

The fuse is located on the ass'y-Inlet. When either the LAMP indicator or the READY indicator is not illuminated, fuse may be opened. Check the fuse as following steps.

- 1. Remove the ass'y-Inlet following to "Mechanical Disassemblies".
- 2. Remove the fuse from fuse holder.
- 3. Check the resistance of fuse by using the tester.

To install the fuse, take reversed step in the above.

It should be used the specified fuse as parts list.




■ OVERHEATING PROTECTION (The temperature monitor system)

The temperature monitor system is provided to prevents damage of component parts inside the projector from overheat.

■ Thermostat Switch: SW902

This function (thermostat switch SW902) will not operate, while the temperature monitor is operating normally. If it has operated, it needs to be reset manually. Disconnect the AC cord first and investigate the cause of overheating. After servicing, reset the thermostat switch (SW902) as shown in a figure.




■ Mechanical Disassemblies

[Attention] This LCD projector is used the different kind of screw. The using correct screw is needed to prevent the damage.


1. CABINET - TOP REMOVAL


1. Remove 6 screws to take the Cabinet Top upward off.



2. CABINET - FRONT REMOVAL


- 1. Open the door.
- 2. Remove a screw to take the Cabinet Front off.





3. MAIN BOARD AND THERMAL BARRIER PLATE REMOVAL


- 1. Remove 7 screws **A** to take the Main Board upward off.
- 2. Remove 2 screws **B** to take the thermal barrier plate upward off.



4. DOOR ASS'Y REMOVAL

1. Remove 6 screws to take the Door Ass'y off.

Note: Can be removed Door itself. See below.



5. DOOR LEG AND DOOR SWITCH BOARD REMOVAL

- 1. Remove a screw to take each leg off.
- 2. Slide the Door Switch Board out.





Fig. 5


6. AV BOARD REMOVAL


- 1. Remove 2 screws **A** to take the AV Ass'y (Board with Panel) upward off.
- 2. Remove 4 screws **B** to take the AV Board off from the AV Panel.



7. LAMP BALLAST UNIT REMOVAL


- 1. Remove 4 screws **A** to take the Filter Holder off.
- 2. Remove 3 screws **B** to take the Filter Board off.
- 3. Remove 3 screws C to take the Inlet Board off.







8. OPTICAL UNIT AND FAN REMOVAL

- 1. Remove a screw **A** to take the Thermostat Switch upward off.
- 2. Remove a screw **B** to take the Lamp Socket off.
- 3. Remove 3 screws C to take the Fan Cover off.
- 4. Remove 8 screws **D** to take the Optical Unit off.
- 5. Remove 4 screws **E** to take the Fan (FAN903) off.









9. POWER BOARD REMOVAL

- 1. Remove 2 screws **A** to take the Lamp SW Board off.
- 2. Remove a screw **B** and 4 screws **C** to open the Power Board Cover and take the R/C Board off.
- 3. Remove 4 screws **D** to take the Power Board off.

Note: For fixing Lamp SW Board, insert the guide to the guide hole of Lamp SW Board and fix the screw of below figure in the beginning.




Note: Remove the Lamp Cover before fixing the Lamp SW board to prevent the damage of Lamp SW board.




10. LAMP BALLAST AND FAN REMOVAL

- 1. Remove 2 screws **A** to take the Lamp Ballast Unit upward off.
- 2. Remove 3 screws ${\bf B}$ to take the Power Board Holder off.
- 3. Remove 4 screws **C** to take the Fan (FN901) off.




11. FANS REMOVAL

- 1. Remove 2 screws **A** and 5 screws **B** to take the Fan Cover off.
- 2. Remove a screw ${\bf C}$ to take the Sensor Board off from tha Fan Cover.
- 3. Remove 2 screws **D** to take the Duct Cover-A off.
- 4. Remove 2 screws **E** to take the Duct Cover-B and Fan (FN902) off.
- 5. Remove a screw **F** to take Fan (FN904) or Fan (FN905) off.



12. DRESSING GROUNDING WIRE




■ Optical Parts Disassemblies

Before Taking this procedure, remove Cabinet Top and Main board following to the "Mechanical Disassemblies".

Disassembly requires a 2.0mm hex wrench and a screwdriver.

1. PROJECTION LENS REMOVAL

1. Remove 2 screws **A** to slide the Lens Spacer and remove 4 screws **B** to take the Projection Lens off.



2. INTEGRATOR LENS REMOVAL

- 1. Remove 2 screws and pull the Integrator Lens Ass'y upward.
- 2. Remove the Stopper and bend four hooks and then take the Lens off from the Holder.

Note:

Should be placed the lens as the rugged surface side of it comes to the holder side.





Fig. 2

3. RELAY LENS REMOVAL

- 1. Remove 2 screws **A** and pull the Relay Lens Ass'y upward.
- 2. Remove 2 screws \boldsymbol{B} to take the Lens off from the Holder.



4. POLARIZED GLASS-IN REMOVAL

- 1. Remove each screw and pull the Polarized Glass-In Ass'y upward.
- 2. Unhook the stoppers and take the glass off upward.

Note:

Should be placed the glass as the film attached side come to the prism side.




Fig. 4

5. POLARIZED GLASS-OUT AND WIDE VIEW PLATE REMOVAL

- 1. Remove 4 screw **A** and take the LCD Panel/Prism Ass'y upward from the Optical Unit.
- 2. Remove each screw B and take the glass off upward.

Note:

- **1.** Fix the plate that the mark is located to left and upper.
 - R,G: Red marking, B: Blue marking
- **2.** Should be replaced the glass as the film attached side comes to the LCD panel side.




Fig. 5

6. OPTICAL UNIT TOP REMOVAL

- 1. Remove Cabinet Top, Cabinet Front, Main Board, AV Board and Filter Ass'y.
- 2. Remove 8 screws to take the Optical Unit Top off upward.





Fig. 6

7. LOCATIONS IN OPTICAL UNIT

When mounting or assembling the optical parts in the optical unit, the parts must be mounted specified location as shown in figure below.



■ LCD Panel/Prism Ass'y Replacement


1. LCD PANEL/PRISM ASS'Y REMOVAL

- 1. Remove Cabinet Top and Main Board.
- 2. Remove 4 screws by a 2.0mm hex wrench to take the Panel/Prism Ass'y off from the Optical Unit.

Note: Do not replace the LCD panel separately otherwise it can not obtain proper picture. Do not touch the prism, the LCD panel and the electrode of flexible cable.

2. LCD PANEL/PRISM ASS'Y ATTACHMENT

1. Tighten 4 screws by a 2.0mm hex wrench to fix the Panel/Prism Ass'y to the Optical Unit.



IMPORTANT NOTICE on LCD Panel/Prism Ass'y Replacement

LCD panels used for this model can not be replaced separately. Do not disassemble the LCD Panel/Prism Ass'y. These LCD panels are installed with precision at the factory. When replacing the LCD panel, should be replaced whole of the LCD panels and prism ass'y at once.

After replacing LCD Panel/Prism ass'y, please check the following adjustments.

- Check the "Condenser Lens Adjustment" and "Relay Lens Adjustment" following to chapter "Optical Adjustment".
- Check the "White Balance Adjustment" and "Common Centre Adjustment" following to chapter "Electrical Adjustment".
- Check the white uniformity on the screen.
 If you find the color shading, please adjust the white uniformity by using the proper computer and "Color Shading Correction" software supplied separately. The software can be ordered as follows;

COLOR SHADING CORRECTION

Service Parts No. 645 056 6288 or 645 066 7428

■ Adjustments After Parts Replacement

● : Adjustment necessary ○ : Check necessary

		Disassembly / Replaced Parts										
		LCD/ Prism Ass'y	Prism Condenser		Polarized glas		_	Wide V		ew B	Power Board	Main Board
ıts	Condenser Lens Adjustment	0	•									
Optical Adjustments	Relay Lens Adjustment	0		•								
Jinst	Contrast Adjustment											
A Ac	R-Contrast adjustment	0			•			•				
ptica	G-Contrast adjustment	0				•			•			
o	B-Contrast adjustment	0					•			•		
	Fan Minimum Adjustment										•	•
	Signal Center Adjustment											•
	Reference Adjustment											•
ents	PC Pedestal Adjustment											•
stm	PC Gain Adjustment											•
Electrical Adjustments	480p Pedestal Adjustment											•
al A	480p Gain Adjustment											•
ctric	480i Gain Adjustment											•
Ele	Video Gain Adjustment											•
	Common Voltage Adjustment	•										•
	50% Luminance Adjustment	•										•
	White Balance Adjustment	0										•

■ Optical Adjustment

Before taking optical adjustments below, remove the Cabinet Top and Main Board following to the "Mechanical Disassemblies"

Adjustments require a 2.0mm hex wrench and a slot screwdriver. When you adjust Integrator lens or Relay lens adjustment, you need to disconnect some connectors and FPC cables of LCD panels on the main board.

Note:

Do not disconnect connectors on the main board, because the projector can not turn on or operate properly for adjustment.

1. CONTRAST ADJUSTMENT


[Before Adjustment]

- Input a 100% of black raster signal.

[R/G/B-CONTRAST ADJUSTMENT]

- 1. Loosen a screw **A** on the polarized glass mounting base which you intend to adjust.
- 2. Turn the polarized glass mounting base as shown in **Fig. 1** to obtain the darkest brightness on the screen.
- 3. Tighten the screw **A** to fix the polarized glass mounting base.

Repeat steps 1 to 3 for remaining polarized glasses.









Fig. 2

2. INTEGRATOR ADJUSTMENT

- 1. Turn the projector on by a state of without FPC cables.
- 2. Project all of lights on the screen.
- 3. Adjust the adjustment base of integrator lens ass'y to make color uniformity in white.








3. RELAY ADJUSTMENT

- 1. Turn the projector on by a state of without FPC cables.
- 2. Project all of lights on the screen.
- Adjust the adjustment base of relay lens ass'y to make color uniformity in white.



■ Electrical Adjustment

■ SERVICE ADJUSTMENT MENU OPERATION

■ To enter service mode

To enter service mode press the "MENU" and "INPUT" buttons on the projector simultaneously and hold for 2 seconds. As shown in a figure, a service mode display appears on a screen.

■ Adjustment

Adjust service data using the following control buttons.

1. "POINT UP" ----- An item number increases.


2. "POINT DOWN" -- An item number decreases.


3. "POINT RIGHT" -- An adjustment value increases.

4. "POINT LEFT" ---- An adjustment value decreases.

■ To exit service mode

Press the "POWER on/off" button only once on the projector or remote control unit to quit the service mode.





■ MEMORY IC REPLACEMENT

IC1841 on the main board stores the data for the service adjustments, and should not be replaced except for the case of defective device.

If replaced, it should be performed the re-adjustments following to the "Electrical Adjustments".

The data of lamp replacement monitor timer is stored in the IC1841.

Please note that the lamp replace counter is reset when the memory IC (IC1841) is replaced.

(Lamp replace counter can not be set to the previous value.)

Caution to memory IC replacement

When IC1841 is replaced with new one, the CPU writes down the default data of the service adjustments to the replaced IC, refer to the service adjustment table. As these data are not the same data as factory shipped data, it should be required to perform

the re-adjustments following to the "Electrical Adjustments".

<u>Please note that in this case the lamp replace counter</u> will be reset.

Caution of Main Board replacement (in the case IC1841 is not defective)

When the main board is replaced, IC1841 should be replaced with the one on previous main board. After replacement, it should be required to perform the readjustments following to the "Electrical Adjustments". In this case, the lamp replace counter can be kept the value as before.

Caution:

Other adjustment items are not related to service and a maintenance. Don't press the POINT (L) and (R) button at the time of those adjustment items. Otherwise it may cause loss of product safety.

[Adjustment Condition]● Input signal1.0Vp-p/75Ω terminated, 16 steps gray scale, white 100% and white 50% pattern (Composite video signal)Computer signal0.7Vp-p/75Ω terminated, 16 steps gray scale pattern (SVGA)Component Video signal0.7Vp-p/75Ω terminated, 16 steps gray scale, white 100% and black 0% pattern (480i format and 480p format)● Picture control mode"STANDARD" mode unless otherwise noted.

Note: Please refer to "Service Adjustment Menu Operation" for entering to the service mode and adjusting the service data.

■ ELECTRICAL ADJUSTMENTS

1. Fan Minimum Voltage Adjustment

Equipment Digital voltmeter Adjustment Value 3.5 ± 0.05 V-DC

Enter the Service mode.

Adjust values of below items by the POINT L or R button.

Item no.	Fan Location	Test Point
100	FN901	TPFAN1
101	FN902	TPFAN2
102	FN903	TPFAN3
103	FN904/5	TPFAN4

2. Signal Center Adjustment

Equipment Digital voltmeter.

Input mode Input 2 [RGB Analog]

Input Signal 16 step gray scale signal

Enter the Service mode.

Adjust below values of each test points by the POINT L or R button.

Item no.	Test Point	Adjustment value
1	TPV1R	6.5 ± 0.05 V-DC.
2	TPV1G	$6.5 \pm 0.05 \text{ V-DC}.$
3	TPV1B	$6.5 \pm 0.05 \text{ V-DC}$.


3. Reference Adjustment

Equipment Oscilloscope
Input mode Input 2 [RGB Analog]
Input Signal 16 step gray scale signal

Enter the Service mode.

Adjust the amplitude of part A to be below value for each test point by the POINT L or R button.

Item no.	Test Point	Adjustment value
10	TP35R	10.0 ± 0.1 Vp-p
11	TP35G	10.0 ± 0.1 Vp-p
12	TP35B	10.0 ± 0.1 Vp-p




4. Pedestal Adjustment (PC & Component)

Equipment Oscilloscope
Input Signal 16 step gray scale signal
4-1 Input mode Input 2 [RGB Analog]
4-2 Input mode Input 2 [Component: 480p]

Enter the Service mode.

Adjust the level of Black and pedestal to be same for each test point by the POINT L or R button **in each mode**.

Item no.	Test Point
203	TP35R
204	TP35G
205	TP35B




5. Gain Adjustment

Equipment	Oscilloscope
Input Signal	16 step gray scale signal
5-1 Input mode	Input 2 [RGB Analog]
5-2 Input mode	Input 2 [Component: 480p]
5-3 Input mode	Input 2 [Component: 480i]
5-4 Input mode	Input 1 [Video: NTSC]

Enter the Service mode.

Adjust below level "**A**" in each test point to be minimum amplitude by the POINT L or R button **in each mode**.

Item no.	Test Point
7	TP35R
8	TP35G
9	TP35B



6. Common Voltage Adjustment

Input mode Input 2 [RGB Analog]
Input Signal 1dot computer signal

Enter the Service mode.

Adjust to be minimum flicker for each color by the POINT L or R button.

<u>ltem no.</u>	Screen
13	Only red color picture
14	Only green color picture
15	Only blue color picture

7. 50% Luminance Adjustment

Input Signal

7-1 Input mode

7-2 Input mode

16 step gray scale signal
Input 2 [RGB Analog]
Input 2 [Component: 480p]

7-3 Input mode

Input 2 [Component: 480i]

Enter the Service mode.

If the black or white saturated picture can be seen, adjust the item "No.16" to be reduced it by the POINT L or R button.

8. White Balance Adjustment

Input Signal 16 step gray scale signal

8-1 Input mode Input 2 [RGB Analog]

8-2 Input mode Input 2 [Component: 480p]

8-3 Input mode Input 2 [Component: 480i]

Enter the Service mode.

Adjust the item "No.17 (Red)" and "No.18 (Blue)" to be good white balance by the POINT L or R button.

Note: The white balance of each mode must be same.

(9. Color Shading Correction)

For the color shading correction, the proper computer and "Color Shading Correction" software are needed.

The software can be ordered as follows.

COLOR SHADING CORRECTION

Service Parts No.

645 056 6288 or 645 066 7428

■ SERVICE ADJUSTMENT DATA TABLE

These initial values are the reference data written from the CPU ROM to memory IC when replaced new memory IC. The adjustment items indicated with "*" are required to readjust following to the "Electrical adjustments". Other items should be used with the initial data value.

		Initial			Detail							
No.	Name		ADS	9882			ronas	Vic	leo	Range		
		PC	DVI	HDCP	YPbPr	YCbCr	SCART	NTSC	PAL	1	480p(+) = 480p + HDTV	
1	R-VIDEOCNT *		•	,	5	3	•	•		0-255		
2	G-VIDEOCNT *				5					0-255	Video Center Adjustment (= RGB - V1)	
	B-VIDEOCNT *				. 5					0-255		
	R-SubBright	0	0	0	0	0				0-1023		
-	G-SubBright	0	0	0	0	0				0-1023		
	B-SubBright R-SubGain *	0 520	0 490	0 490	530	0 530		0 530		0-1023 0-1023	Cain Adjustment [D]	
	R-SubGain * G-SubGain *	520	490	490	530	530		530		0-1023	Gain Adjustment [R] Gain Adjustment [G]	
	B-SubGain *	520	490	490	530	530		530		0-1023	Gain Adjustment [B]	
	REF-R	- 020		1	14					0-255	Gam ridge and rigge	
	REF-G				14					0-255		
12	REF-B				14	10				0-255		
	BVCOM *				9	5				0-255		
	GVCOM *				9					0-255	Common Center Adjustment	
$\overline{}$	RVCOM *				9					0-255		
	G-GammaShift *	512	500	500	512	512		512		0-1023	Gamma Adjustment	
_	R-GammaShift *	512	500	500	512	512		512		0-1023	White Balance Adjustment [R]	
-	B-GammaShift * R-V2	512	500	500	512	512		512		0-1023 0-255	White Balance Adjustment [B] Link to No.1	
	G-V2				(8 (8)					0-255	Link to No.1 Link to No.2	
	B-V2				(8					0-255	Link to No.3	
-	SubBright	128	128	128	128	128	128	128	128	-		
	SubColor				96	95	95	95	95	-		
26	SubTint				0	0	0	0	0	-		
28	SubBright(Video)						128	128	128	0-255		
	SubCont(Video)						55	55	56	0-63		
	SubColor(Video)						2070	2070	2070	0-4095		
	SubTint(Video)							512	512	0-1023		
	SubBright(480i,575i)					196	196			0-255		
	SubCont(480i,575i)					21	23	25	25	0-63	E75; in linked to DAI	
	SubColor-Cb(480i,575i) SubColor-Cr(480i,575i)					35 35	23 29	35 35	35 35	0-63 0-63	575i is linked to PAL 480i is linked to NTSC	
	SubTint(480i,575i)					32	23	32	32	0-63	400 IS IIIRed to NTSC	
	YC Delay					62	62	62	62	0-63		
	SubSharpness					<u> </u>		0	0	-		
-	V-Line Color Shading Correction <r1></r1>				2	2		•		0-255		
40	V-Line Color Shading Correction <r2></r2>									0-255		
-	V-Line Color Shading Correction <r3></r3>				25					0-255		
	V-Line Color Shading Correction <g1></g1>				- 2					0-255		
	V-Line Color Shading Correction <g2></g2>									0-255		
	V-Line Color Shading Correction <g3></g3>				25					0-255		
	V-Line Color Shading Correction <b1></b1>					2				0-255		
	V-Line Color Shading Correction <b2> V-Line Color Shading Correction <b3></b3></b2>				25					0-255 0-255		
	<r>Reference Voltage (H)</r>				10					0-233		
-	<r>Reference Voltage (L)</r>				42					0-1023		
	<g>Reference Voltage (H)</g>					16				0-1023		
	<g>Reference Voltage (L)</g>				42					0-1023		
	Reference Voltage (H)				10					0-1023		
	Reference Voltage (L)				42	20				0-1023		
54										-	 	
	Color Shading Correction ON/OFF				1					-	V-Line Correction	
	LampLifeTime BauRate									-	Display Only 0;9600/ 1;19200/ 2;38400	
	ShootOutMode				(-	0;9600/ 1;19200/ 2;38400 0;Normal/ 1;Shoot out1/ 2;Shoot out2	
	PC Frame Lock				(-	0: Unlocked, 1: 45MHz-60.1MHz Locked	
	Forced NoBrand				(-	0: Normal, 1: No Brand	
	AutoGrayScaleTune											
70	White Controlled Starting Point				3	0				0-255		
	White Controlled Limit Point				6	1				0-255		
	White Controlled Starting Point				Ç					0-255		
73	White Controlled Limit Point				-	<u> </u>				0-255		
100	FAN CONTROL				_	0				0.055	[
-	Fan1 Min Adjust *				2					0-255	Fan Voltage: 3.5V Adjustment	
_	Fan2 Min Adjust * Fan3 Min Adjust *				2					0-255 0-255		
	Fan3 Min Adjust * Fan4 Min Adjust *									0-255		
100	r arr i viiii / i ujuot		28						1 2 2 2 3 3	l .		

					Init	tial			Detail		
No.	Name	PC	AD9882 Micronas Video PC DVI HDCP YPbPr YCbCr SCART NTSC PAL							Range	Note: $480i(+) = 480i + 575i$ 480p(+) = 480p + HDTV
	Fan1 Max Adjust				18						Fan Voltage: 14.5V Adjustment
	Fan2 Max Adjust				18				0-255 0-255		
	Fan3 Max Adjust Fan4 Max Adjust		185 185								
	Fan Control Mode		0							0-255 0-4	0:Normal,1:Cell, 2:Wall, 3:H-Pressure, 4:Manual
	Fan Max Min SW	0							0:Auto Fan Control,1:Min,2:Max		
		Normal	Cell	Wall	H-Pre						, ,
	Fan1 Min	80	80	80	85						Fan Minimum Voltage (Normal)
-	Fan2 Min	50	50	50	60					30-145	
	Fan3 Min Fan4 Min	90 45	90 45	90 45	110 70					30-145 30-145	
	Fan1 Max	110	110	110	120						Fan Maximum Voltage (Normal)
	Fan2 Max	95	95	95	95					30-145	- an manning condition
	Fan3 Max	132	132	132	132					30-145	
	Fan4 Max	135	135	135	135					30-145	
-	TempA Low	30	30	30	29					10-100	
	TempA High Eco Fan1 Min	38 55	38 55	38 55	38 85					10-100 30-145	Fan Minimum Voltage (Eco)
_	Eco Fan Min	35	35	35	55					30-145	. a. wiiminani voitage (Loo)
	Eco Fan3 Min	58	58	58	90					30-145	
	Eco Fan4 Min	35	35	35	60					30-145	
	Eco Fan1 Max	75	75	75	105						Fan Maximum Voltage (Eco)
	Eco Fan2 Max	50	50	50	60					30-145	
	Eco Fan3 Max Eco Fan4 Max	90 90	90	90	100 110					30-145 30-145	
	Eco TempA Low	30	30	30	29					10-100	
	Eco TempA High	38	38	38	38					10-100	
130	TempA Error	43	44	44	40					10-100	
	TempB Error	80	80	80	80					10-100	
	TempC Error	54	54	55	45					10-100	
	TempB-A Error TempC-A Error	50 32	50 32	50 32	33 20					10-100 10-100	
	TempB Low UP	32	32	J 32	6	3				10-100	
-	TempB High Up				6					10-100	
	TempB Low Down	41									
	TempB High Down	42									
	Manual Fan1 Voltage	100									Fan Operating Voltage (Manual)
	Manual Fan2 Voltage Manual Fan3 Voltage				10				30-145 30-145		
	Manual Fan4 Voltage				10				30-145		
	Temp Error Cooling Time				3					0:Always,1:30s, 2:60s, / /, 15:450s	
	Cooling Time				3					0-15	1:30s, 2:60s, 3:90s, / /, 15:450s
	average time				2	2				1-5	
	ECO LAMP TIME									-	
	NORMAL LAMP TIME PROJECTOR TIME									-	
-	VPC3230										
	Notch Filter Select							3	0	-	
	diagonal dot reduction							1	0	-	
	horizontal differential gain							2	1	-	
	vertical differential gain							3 7	3 7	-	
	vertical peaking gain AFC Other 1							540	540	-	
	AFC Other 2							536	536	-	
157	Horizontal Peaking Filter					2	2	1	1	-	
	Peaking Gain					1	1	2	2	-	
	peaking filter coring enable					0	0	0	0	-	0.105 1.400 ON
	AGC On/OFF Horizontal Lowpass Filter					1	1	0	0	-	0:165, 1:AGC ON
	Horizontal Lowpass Filter Chroma					0	0	0	0	-	
	DOR					0	0	0	0	-	
164	COR					0	0	0	0	-	
	SGAIN							22	22	-	
	ADC	70			l 70					0.055	
	REDGAIN GRNGAIN	70 70			70 70					0-255 0-255	
	BLUGAIN	70			70					0-255	
	REDOFST *	60			70					0-233	

No. Name 204 GRNOFST 205 BLUOFST 208 209 RACLP	*	PC	AD9	9882	Init	Micro	nnae	Vic	leo	Range	Detail
205 BLUOFST 208		PC						litaliae	Note: 480i(+) = 480i + 575i		
205 BLUOFST 208			ואט	HDCP	YPbPr	YCbCr	SCART	NTSC	PAL		480p(+) = 480p + HDTV
208	4	60			55					0-127	
	小	60			70					0-127	
		0			0					- 0.0FF	D Clamp Valtage Catting
210 GACLP		0			0						B Clamp Voltage Setting G Clamp Voltage Setting
211 BACLP		0			0						R Clamp Voltage Setting
219 DLY3.3V ON]				10	00				-	Timing from Power On to 3.3V
220 DLY5V_ON					10	00				-	Timing from 3.3V to 5V
221										-	
230 NTSC(480i)C		2								-	
231 NTSC(480i)C		36									
232 PAL(575i)Cla 233 PAL(575i)Cla		4 45								-	
234 SVGA Clamp		3								-	
235 SVGA Clamp		20								-	
236 XGA Clamp I		4								-	
237 XGA Clamp		30								-	
238 VGA Clamp I	Placement	3								-	
239 VGA Clamp		23								-	
240 SXGA Clamp 241 SXGA Clamp		7 32								-	
242 MAC Clamp		5 5								-	
243 MAC Clamp		44								-	
244 480p Clamp		10								-	RGB
245 480p Clamp	Duration	20								-	RGB
246 575p Clamp		3								-	RGB
247 575p Clamp		20								-	RGB
248 1080i Clamp		55								-	RGB
249 1080i Clamp 250 1080i 50 Cla		20 45								-	RGB
251 1080i_50 Cla		36								-	RGB
252 1035i Clamp		48								-	RGB
253 1035i Clamp	Duration	36								-	RGB
254 720p Clamp		48								-	RGB
255 720p Clamp		36								-	RGB
256 480p Clamp 257 480p Clamp					16					-	Component
258 575p Clamp					80 24					-	Component Component
259 575p Clamp					80					-	Component
260 1080i Clamp					10					-	Component
261 1080i Clamp	Duration				10					-	Component
262 1080i_50 Cla					7					-	Component
263 1080i_50 Cla					70					-	Component
264 1035i Clamp					7					-	Component
265 1035i Clamp 266 720p Clamp					60 7					<u> </u>	Component Component
267 720p Clamp					80					-	Component
Over Scan	- 2. 300										
300 Expand Ratio								1		-	Video and S-Video mode only.
301 Expand Ratio	(Horizontal) 60Hz							4		-	Progressive OFF
302 Position (Hor								512		-	
303 Position (Ver								384	-	-	
304 Expand Ratio									5 4	-	
306 Position (Hor	(Horizontal) 50Hz								512	-	
307 Position (Ver									383	-	
308 Expand Ratio						1				-	For Component 480i mode
309 Expand Ratio						3				-	Progressive OFF
310 Position (Hor						515				-	
311 Position (Ver						384				-	
312 Expand Ratio						5				-	For Component 575i mode
313 Expand Ration 314 Position (Hor						4 511				-	Progressive OFF
314 Position (Hor						383				-	
316 Expand Ratio					10					-	For Component 480p mode
	(Horizontal) 480p				34					-	
318 Position (Hor					512					-	
319 Position (Ver	tical) 480p				383					-	


					Ini	tial			Detail		
No.	Name	AD9882 Micronas Video									
		PC	DVI	HDCP	YPbPr	YCbCr			PAL	Range	480p(+) = 480p + HDTV
320	Expand Ratio (Vertical) 575p			-	14					-	For Component 575p mode
	Expand Ratio (Horizontal) 575p				27					-	
	Position (Horizontal) 575p				485					-	
323	Position (Vertical) 575p				394					-	
	Expand Ratio (Vertical) 720p				10					-	For Component 720p mode
	Expand Ratio (Horizontal) 720p				16					-	
	Position (Horizontal) 720p				524					-	
	Position (Vertical) 720p				384					-	
	Expand Ratio (Vertical) 1035i				7					-	For Component mode and RGB HDTV 1035i
	Expand Ratio (Horizontal) 1035i				24					-	
	Position (Horizontal) 1035i Position (Vertical) 1035i				529					-	
_	Expand Ratio (Vertical) 1080i				384 7					-	For Component mode and RGB HDTV 1080i
_	Expand Ratio (Vertical) 1080i				24					-	For Component mode and RGB RD1 V 10801
	Position (Horizontal) 1080i				522						
	Position (Vertical) 1080i				377					-	
	Expand Ratio (Vertical) 60Hz	14								-	RGB NTSC
	Expand Ratio (Horizontal) 60Hz	31								-	
	Position (Horizontal) 60Hz	506								-	
	Position (Vertical) 60Hz	383								-	
	Expand Ratio (Vertical) 50Hz	10								-	RGB PAL
341	Expand Ratio (Horizontal) 50Hz	22								-	
	Position (Horizontal) 50Hz	498								-	
343	Position (Vertical) 50Hz	385								-	
344	Expand Ratio (Vertical) 50Hz				8					-	1080i_50Hz and RGB HDTV 1080i@50
	Expand Ratio (Horizontal) 50Hz				16					-	
	Position (Horizontal) 50Hz				512					-	
	Position (Vertical) 50Hz				384	<u> </u>				-	
	Expand Ratio (Vertical) SCART						5			-	SCART
	Expand Ratio (Horizontal) SCART						4			-	Progressive OFF
	Position (Horizontal)SCART						513			-	
	Position (Vertical) SCART						383			-	10.77
	Expand Ratio (Vertical) 60Hz							2		-	Video and S-Video mode only.
	Expand Ratio (Horizontal) 60Hz							4		-	Progressive ON
	Position (Horizontal) 60Hz							512		-	
	Position (Vertical) 60Hz Expand Ratio (Vertical) 50Hz							383	5	-	
	Expand Ratio (Horizontal) 50Hz								4	-	
	Position (Horizontal) 50Hz								512	-	
	Position (Vertical) 50Hz								383	_	
	Expand Ratio (Vertical) 480i					l 1				-	For Component 480i mode
	Expand Ratio (Horizontal) 480i					3				-	Progressive ON
	Position (Horizontal) 480i					512				-	3
363	Position (Vertical) 480i					383				-	
	Expand Ratio (Vertical) 575i					5				-	For Component 575i mode
365	Expand Ratio (Horizontal) 575i					4				-	Progressive ON
366	Position (Horizontal) 575i					511				-	
	Position (Vertical) 575i					383				-	
	Expand Ratio (Vertical) SCART						5			-	SCART
	Expand Ratio (Horizontal) SCART						4			-	Progressive ON
	Position (Horizontal)SCART						513			-	
_	Position (Vertical) SCART						383			-	100 100
	Expand Ratio (Vertical) 60Hz				10					-	480p and RGB 480p
	Expand Ratio (Horizontal) 60Hz				34					<u> </u>	
	Position (Horizontal) 60Hz				506					-	
	Position (Vertical) 60Hz				376					-	E75n and BCR E75n
	Expand Ratio (Vertical) 50Hz				14 27					-	575p and RGB 575p
_	Expand Ratio (Horizontal) 50Hz Position (Horizontal) 50Hz				485					-	
	Position (Honzontal) 50Hz				394					-	
	Expand Ratio (Vertical)				10	10		10	10	-	CAPTION IN
381	Expand Hallo (Vertical)				10	10		10	10		
382										-	
	Position (Vertical)				384	384		384	384	-	
	Expand Ratio (Vertical) 1035i	7							301	-	For RGB HDTV 1035i
	Expand Ratio (Horizontal) 1035i	24								-	
	Position (Horizontal) 1035i	526								-	
	Position (Vertical) 1035i	384								-	
_	` '										<u> </u>


■ Adjustment


	Name				Init	tial			Detail		
No.		AD9882				Mici	ronas	Video		Range	Note: 480i(+) = 480i + 575i
		PC	DVI	HDCP	YPbPr	YCbCr	SCART	NTSC	PAL		480p(+) = 480p + HDTV
388	Expand Ratio (Vertical) 1080i	8	8								For RGB HDTV 1080i
389	Expand Ratio (Horizontal) 1080i	24									
390	Position (Horizontal) 1080i	519									
391	Position (Vertical) 1080i	377								-	
392	Expand Ratio (Vertical) 50Hz	7								-	For RGB HDTV 1080i@50
393	Expand Ratio (Horizontal) 50Hz	16	16								
394	Position (Horizontal) 50Hz	504								-	
395	Position (Vertical) 50Hz	384								-	
396	HDCP			0						-	From 0 to 5
500	Service, 16,17,18 Link Flag					0				-	0: Non Link, 1: Link


■ Test Points and Locations


■ MAIN BOARD












■ Troubleshooting


No Power

Refer to Schematic Diagram or Power Supply Line, find out the part of trouble. Before opening Cabinet Top, check the AC cord and power source.




No Picture


Refer to Schematic Diagram or Block Diagram (P34), find out the part of trouble. In advance check the setting mode or connections according to Owner's Manual.




BA7078AF <Sync-Separation, IC5321>




● BA9743AFV <IC371>




● L3E07070K0A <Color Shading Correction, IC401>




■ TA1370FG <Sync-Separation, IC5341>




VPC3230D <Video Decoder, IC101>



● AD9882KST <A/D, IC8201>




● AN5870SB <PC/AV SW, IC5201>



■ Electrical Parts List

Product safety should be considered when a component replacement is made in any area of a projector. Components indicated by a \triangle mark in this parts list and the circuit diagram show components whose value have special significance to product safety. It is particularly recommended that only parts specified on the following parts list be used for components replacement pointed out by the mark.



<u>Electrical P</u>	Electrical Parts List						
Key No.	Part No.	Description	Key No.	Part No.	Description		
OUT OF CIF	RCUIT BOARD			405 002 6904	TR 2SA1179-M7-TB		
△ LP901	610 309 7589	COMPL,OPTICAL LMP-M4KA		405 163 1503	TR 2SA1179N-M6-TB		
L901	645 040 2593	CORE, FERRITE		405 163 2708 405 173 9605	TR 2SA1179N-M7-TB TR 2SA1235A1E		
L902	645 065 4510	CORE, FERRITE		405 173 9704	TR 2SA1235A1F		
MISCELLAN	NEOUS		Q5311	405 014 4509	TR 2SC2412K T146 R		
△ A601	645 061 9151	UNIT, POWER		405 014 4608	TR 2SC2412K T146 S		
△ A901	645 061 9168	UNIT, BALLAST		405 015 8704 405 015 8902	TR 2SC2812-L6-TB		
△ FN901	645 062 5145	MOTOR, FAN DC 2.28W		405 015 8902	TR 2SC2812-L7-TB TR 2SC2812N-L6-TB0		
\triangle FN902	645 062 5398	MOTOR, FAN DC 2.65W		405 163 1701	TR 2SC2812N-L7-TB0		
⚠ FN903	645 063 9463	MOTOR, FAN DC 2.04W		405 173 9803	TR 2SC3928A1R		
\triangle FN904	645 062 5572	MOTOR, FAN DC 2.65W		405 173 9902	TR 2SC3928A1S		
\triangle FN905	645 062 5572	MOTOR, FAN DC 2.65W	Q5312	405 014 4509	TR 2SC2412K T146 R		
△ SW902	645 026 5457	SWITCH, THERMAL		405 014 4608 405 015 8704	TR 2SC2412K T146 S TR 2SC2812-L6-TB		
	645 048 3158	SWITCH, THERMAL		405 015 8902	TR 2SC2812-L7-TB		
610 307 889	2 ASSY.PWB.MA	AIN M4KA 1AA0B10C4780A		405 163 1602	TR 2SC2812N-L6-TB0		
				405 163 1701	TR 2SC2812N-L7-TB0		
TRANSISTO				405 173 9803 405 173 9902	TR 2SC3928A1R		
Q1841 Q1842	405 045 8705 405 045 8705	TR 2SK536-TB TR 2SK536-TB	Q5621	405 173 9902	TR 2SC3928A1S TR 2SA1203-Y-TE12L		
Q1843	405 045 8705	TR 2SK536-TB	Q5622	405 014 4509	TR 2SC2412K T146 R		
Q1844	405 045 8705	TR 2SK536-TB	~	405 014 4608	TR 2SC2412K T146 S		
Q1891	405 014 4509	TR 2SC2412K T146 R		405 015 8704	TR 2SC2812-L6-TB		
	405 014 4608	TR 2SC2412K T146 S		405 015 8902	TR 2SC2812-L7-TB		
	405 015 8704 405 015 8902	TR 2SC2812-L6-TB TR 2SC2812-L7-TB		405 163 1602 405 163 1701	TR 2SC2812N-L6-TB0 TR 2SC2812N-L7-TB0		
	405 163 1602	TR 2SC2812N-L6-TB0		405 173 9803	TR 2SC3928A1R		
	405 163 1701	TR 2SC2812N-L7-TB0		405 173 9902	TR 2SC3928A1S		
	405 173 9803	TR 2SC3928A1R	Q5641	405 002 8304	TR 2SA1203-Y-TE12L		
	405 173 9902	TR 2SC3928A1S	Q5642	405 014 4509	TR 2SC2412K T146 R		
Q301 Q371	405 045 8705 406 017 8402	TR 2SK536-TB TR RTQ025P02-TR		405 014 4608 405 015 8704	TR 2SC2412K T146 S TR 2SC2812-L6-TB		
Q371 Q372	406 017 8402	TR RTQ025P02-TR		405 015 8902	TR 2SC2812-L7-TB		
Q4601	405 002 8304	TR 2SA1203-Y-TE12L		405 163 1602	TR 2SC2812N-L6-TB0		
Q4603	405 014 4509	TR 2SC2412K T146 R		405 163 1701	TR 2SC2812N-L7-TB0		
	405 014 4608	TR 2SC2412K T146 S		405 173 9803	TR 2SC3928A1R		
	405 015 8704 405 015 8902	TR 2SC2812-L6-TB TR 2SC2812-L7-TB	Q6201	405 173 9902 405 014 4509	TR 2SC3928A1S TR 2SC2412K T146 R		
	405 013 8902	TR 2SC2812-L7-1B	Q0201	405 014 4608	TR 2SC2412K T146 K		
		TR 2SC2812N-L7-TB0		405 015 8704	TR 2SC2812-L6-TB		
		TR 2SC3928A1R		405 015 8902			
		TR 2SC3928A1S			TR 2SC2812N-L6-TB0 TR 2SC2812N-L7-TB0		
Q5301	405 014 4509 405 014 4608	TR 2SC2412K T146 R TR 2SC2412K T146 S		405 173 9803			
	405 015 8704	TR 2SC2812-L6-TB		405 173 9902			
	405 015 8902	TR 2SC2812-L7-TB	Q6202	405 014 4509			
	405 163 1602			405 014 4608			
	405 163 1701	TR 2SC2812N-L7-TB0		405 015 8704 405 015 8902			
	405 173 9803 405 173 9902	TR 2SC3928A1R TR 2SC3928A1S		405 163 1602			
Q5302	405 134 5905	TR 2SA1037AK-T146-R		405 163 1701			
	405 147 2205	TR 2SA1037AK-S-T146		405 173 9803			
	405 002 0308			405 173 9902			
	405 002 0407	TR 2SA1037K T146 S	Q6211	405 014 4509 405 014 4608			
	405 002 6706 405 002 6904	TR 2SA1179-M6-TB TR 2SA1179-M7-TB		405 014 4008	TR 2SC2812-L6-TB		
	405 163 1503	TR 2SA1179N-M6-TB		405 015 8902			
		TR 2SA1179N-M7-TB	1	405 163 1602			
	405 173 9605		1	405 163 1701			
05333	405 173 9704	TR 2SA1235A1F		405 173 9803 405 173 9902	TR 2SC3928A1R TR 2SC3928A1S		
Q5303	405 134 5905 405 147 2205	TR 2SA1037AK-T146-R TR 2SA1037AK-S-T146	Q6212	405 173 9902			
	405 147 2203	TR 2SA1037AK-S-1140 TR 2SA1037K T146 R	~	405 014 4608			
	405 002 0407	TR 2SA1037K T146 S		405 015 8704			
	405 002 6706	TR 2SA1179-M6-TB	1	405 015 8902	TR 2SC2812-L7-TB		

Key No.	Part No.	Description	Key No.	Part No.	Description
	405 163 1602	TR 2SC2812N-L6-TB0		405 163 1701	TR 2SC2812N-L7-TB0
	405 163 1701	TR 2SC2812N-L7-TB0		405 173 9803	TR 2SC3928A1R
	405 173 9803	TR 2SC3928A1R		405 173 9902	TR 2SC3928A1S
	405 173 9902	TR 2SC3928A1S	Q8101	405 014 4509	TR 2SC2412K T146 R
Q6221	405 014 4509	TR 2SC2412K T146 R		405 014 4608	TR 2SC2412K T146 S
	405 014 4608	TR 2SC2412K T146 S		405 015 8704	TR 2SC2812-L6-TB
	405 015 8704	TR 2SC2812-L6-TB		405 015 8902	TR 2SC2812-L7-TB
	405 015 8902	TR 2SC2812-L7-TB		405 163 1602	TR 2SC2812N-L6-TB0
	405 163 1602 405 163 1701	TR 2SC2812N-L6-TB0 TR 2SC2812N-L7-TB0		405 163 1701 405 173 9803	TR 2SC2812N-L7-TB0 TR 2SC3928A1R
	405 163 1701	TR 2SC2012N-L/-1BU		405 173 9903	TR 2SC3928A1S
	405 173 9902	TR 2SC3928A1S	Q8111	405 045 8705	TR 2SK536-TB
Q6222	405 014 4509	TR 2SC2412K T146 R	Q8112	405 045 8705	TR 2SK536-TB
-	405 014 4608	TR 2SC2412K T146 S	Q8121	405 014 4509	TR 2SC2412K T146 R
	405 015 8704	TR 2SC2812-L6-TB		405 014 4608	TR 2SC2412K T146 S
	405 015 8902	TR 2SC2812-L7-TB		405 015 8704	TR 2SC2812-L6-TB
	405 163 1602	TR 2SC2812N-L6-TB0		405 015 8902	TR 2SC2812-L7-TB
	405 163 1701	TR 2SC2812N-L7-TB0		405 163 1602	TR 2SC2812N-L6-TB0
	405 173 9803	TR 2SC3928A1R		405 163 1701	TR 2SC2812N-L7-TB0
06221	405 173 9902	TR 2SC3928A1S		405 173 9803	TR 2SC3928A1R
Q6231	405 014 4509 405 014 4608	TR 2SC2412K T146 R TR 2SC2412K T146 S	Q8131	405 173 9902 405 045 8705	TR 2SC3928A1S TR 2SK536-TB
	405 014 4008	TR 2SC2812-L6-TB	Q8131 Q8132	405 045 8705	TR 2SK536-TB
	405 015 8902	TR 2SC2812-L7-TB	Q8141	405 014 4509	TR 2SC2412K T146 R
	405 163 1602	TR 2SC2812N-L6-TB0	~ -	405 014 4608	TR 2SC2412K T146 S
	405 163 1701	TR 2SC2812N-L7-TB0		405 015 8704	TR 2SC2812-L6-TB
	405 173 9803	TR 2SC3928A1R		405 015 8902	TR 2SC2812-L7-TB
	405 173 9902	TR 2SC3928A1S		405 163 1602	TR 2SC2812N-L6-TB0
Q6241	405 014 4509	TR 2SC2412K T146 R		405 163 1701	TR 2SC2812N-L7-TB0
	405 014 4608	TR 2SC2412K T146 S		405 173 9803	TR 2SC3928A1R
	405 015 8704	TR 2SC2812-L6-TB	00001	405 173 9902	TR 2SC3928A1S
	405 015 8902	TR 2SC2812-L7-TB	Q8201	405 045 8705 405 045 8705	TR 2SK536-TB
	405 163 1602 405 163 1701	TR 2SC2812N-L6-TB0 TR 2SC2812N-L7-TB0	Q8202 Q8851	406 018 3307	TR 2SK536-TB TR 2SD1383K T146 B
	405 173 9803	TR 2SC3928A1R	Q8852	406 018 3307	TR 2SD1383K T146 B
	405 173 9902	TR 2SC3928A1S			IN ZODISOSK IIIO D
Q6251	405 014 4509	TR 2SC2412K T146 R	INTEGRATE		
	405 014 4608	TR 2SC2412K T146 S	IC101	410 401 4604	IC VPC3230D-QA-B3
	405 015 8704	TR 2SC2812-L6-TB	IC1301 IC1321	409 501 9107 409 462 2407	IC ICS512MT IC TC7SZ08FU-(TE85L)
	405 015 8902	TR 2SC2812-L7-TB	IC1321 IC1501	409 560 6604	IC L3E06110D0A
	405 163 1602	TR 2SC2812N-L6-TB0	IC1501		IC PQ033EZ01ZP
		TR 2SC2812N-L7-TB0	IC1801		IC TC74LCX574FT
		TR 2SC3928A1R TR 2SC3928A1S	IC1802	410 346 8804	IC TC74LCX574FT
Q6271		TR 2SC2412K T146 R	IC1803	410 346 8804	IC TC74LCX574FT
20271		TR 2SC2412K T146 S	IC1811	410 362 6501	IC TC74LCX541FT
		TR 2SC2812-L6-TB	IC1831		IC TC74LCX541FT
	405 015 8902	TR 2SC2812-L7-TB	IC1841		IC 24LC32AT-I/SN
	405 163 1602	TR 2SC2812N-L6-TB0	IC1861		IC HD74LVC14T
	405 163 1701	TR 2SC2812N-L7-TB0	IC1871 IC1881		IC M51204FP-600C IC MC74VHC14DT
		TR 2SC3928A1R	IC1882		IC PIC12F675-I/SNC322A
		TR 2SC3928A1S	IC1883		IC TC7SET32FU-(TE85L)
Q6281		TR 2SA1037AK-T146-R	IC1891		IC MC74ACT00DT
		TR 2SA1037AK-S-T146 TR 2SA1037K T146 R	IC1895		IC TC7SU04F-(TE85L)
		TR 2SA1037K T146 K	IC1897	409 155 8006	IC TC7S04F-TE85L
		TR 2SA1037K 1140 3	IC2501	409 560 6604	IC L3E06110D0A
		TR 2SA1179-M7-TB	IC301		IC PW168A-10V
		TR 2SA1179N-M6-TB	IC341	409 480 1307	
	405 163 2708	TR 2SA1179N-M7-TB	IC351		IC TC7W126FU-(TE12L)
		TR 2SA1235A1E	IC361		IC TC7WZ32FU IC BA9743AFV-E2
		TR 2SA1235A1F	IC371 IC392		IC BA9743AFV-E2 IC SI-3025LSA-TL
Q7821		TR 2SC2412K T146 R	IC401		IC L3E07070K0A
		TR 2SC2412K T146 S	IC4501	409 428 9600	
		TR 2SC2812-L6-TB TR 2SC2812-L7-TB	IC4531	409 428 9600	
		TR 2SC2812N-L6-TB0	IC4551	409 246 9707	IC LA6358NM-TE-L
	100 100 1002				

Electrical Pa					
Key No.	Part No.	Description	Key No.	Part No.	Description
IC491	409 555 6404	IC SI-3018KS-TL	C144	403 155 1609	CERAMIC 33P J 50V
IC501	409 560 6604	IC L3E06110D0A	C146	403 155 1609	CERAMIC 33P J 50V
IC5321	409 484 2003	IC BA7078AF-E2	C147	403 281 5205	CERAMIC 0.22U Z 16V
IC5341	409 545 7503	IC TA1370FG	C148	403 281 5205	CERAMIC 0.22U Z 16V
IC5351	409 124 5708	IC L78M09T-TR	C149	403 281 5205	CERAMIC 0.22U Z 16V
IC5361	410 488 3408	IC TC74LVX125FT	C1501	403 164 0204	CERAMIC 0.1U Z 25V
IC5631	409 539 8905	IC PQ033EZ01ZP	C1502	403 164 0204	CERAMIC 0.1U Z 25V
IC5641	409 124 5906 410 510 4809	IC L78M12T-TL IC MBM29DL32TF70C326B	C1507	403 164 0204 403 281 5205	CERAMIC 0.1U Z 25V CERAMIC 0.22U Z 16V
IC801 IC801A	410 510 4809	IC MBM29DL32TF70C326B	C151 C1512	403 281 5205	CERAMIC 0.22U Z 16V CERAMIC 0.1U Z 25V
IC8101	410 480 1000	IC TC74HC4053AFT(EL)	C1512	403 164 0204	CERAMIC 0.10 Z 25V
IC8111	409 417 5507	IC 24LC04BT/SN	C1514	403 164 0204	CERAMIC 0.10 Z 25V
IC8121	410 358 1503	IC TC74HC4053AFT(EL)	C152	403 281 5205	CERAMIC 0.22U Z 16V
IC8131	409 417 5507	IC 24LC04BT/SN	C1521	403 164 0204	CERAMIC 0.1U Z 25V
IC8141	409 451 2807	IC TC7W66FK-(TE85L)	C1522	403 164 0204	CERAMIC 0.1U Z 25V
IC8151	409 451 2807	IC TC7W66FK-(TE85L)	C1523	403 164 0204	CERAMIC 0.1U Z 25V
IC8161	410 495 1107	IC 24LC04BT/SNP-C356	C1524	403 164 0204	CERAMIC 0.1U Z 25V
IC8201	410 476 5605	IC AD9882KST-100	C1525	403 164 0204	CERAMIC 0.1U Z 25V
IC8251	409 439 8906	IC TC7WH125FU	C1526	403 164 0204	CERAMIC 0.1U Z 25V
IC8801	409 481 8602	IC LM76CHMX-5	C1527	403 164 0204	CERAMIC 0.1U Z 25V
IC8802	409 481 8602	IC LM76CHMX-5	C153	403 281 5205	CERAMIC 0.22U Z 16V
IC9401	410 403 7900	IC LC24085BT-UG4	C1531	403 229 3508	ELECT 100U M 16V
IC9801	409 466 6906	IC SP232ECT	C1532	403 335 0408 403 164 0204	ELECT 100U M 16V CERAMIC 0.1U Z 25V
CAPACITOR	ì		C1532 C1533	403 164 0204	CERAMIC 0.1U Z 25V CERAMIC 0.1U Z 25V
C104	403 281 5205	CERAMIC 0.22U Z 16V	C1533	403 164 0204	CERAMIC 0.10 Z 25V
C105	403 215 0900	CERAMIC 390P J 50V	C1534	403 164 0204	CERAMIC 0.10 Z 25V
C106	403 281 5205	CERAMIC 0.22U Z 16V	C1537	403 164 0204	CERAMIC 0.1U Z 25V
C107	403 281 5205	CERAMIC 0.22U Z 16V	C1538	403 164 0204	CERAMIC 0.1U Z 25V
C108	403 281 5205	CERAMIC 0.22U Z 16V	C1539	403 164 0204	CERAMIC 0.1U Z 25V
C109	403 157 3304	CERAMIC 68P J 50V	C154	403 379 6701	CERAMIC 10U K 16V
C111	403 379 6701	CERAMIC 10U K 16V	C156	403 164 0204	CERAMIC 0.1U Z 25V
C112 C113	403 205 2808 403 281 5205	CERAMIC 0.047U K 25V CERAMIC 0.22U Z 16V	C157	403 322 7809	ELECT 220U M 6.3V
C114	403 281 3203	CERAMIC 0.220 Z 10V CERAMIC 1500P K 50V		403 349 4706	ELECT 220U M 6.3V
C114	403 215 0900	CERAMIC 390P J 50V	C158	403 164 0204	CERAMIC 0.1U Z 25V
C117	403 281 5205	CERAMIC 0.22U Z 16V	C1801	403 164 0204	CERAMIC 0.1U Z 25V
C118	403 379 6701	CERAMIC 10U K 16V	C1802 C1803	403 164 0204 403 164 0204	CERAMIC 0.1U Z 25V CERAMIC 0.1U Z 25V
C119	403 205 2808	CERAMIC 0.047U K 25V	C1803	403 164 0204	CERAMIC 0.10 Z 25V
C121	403 215 0900	CERAMIC 390P J 50V	C1831	403 164 0204	CERAMIC 0.10 Z 25V
C122	403 155 2101	CERAMIC 1500P K 50V	C1841	403 164 0204	CERAMIC 0.1U Z 25V
C123	403 281 5205		C1863	403 164 0204	CERAMIC 0.1U Z 25V
C124	403 157 1508	CERAMIC 3P C 50V	C1871	403 283 6309	CERAMIC 1U Z 10V
C125	403 322 7809	ELECT 220U M 6.3V	C1872	403 283 6309	CERAMIC 1U Z 10V
0126	403 349 4706	ELECT 220U M 6.3V	C1873	403 283 6309	CERAMIC 1U Z 10V
C126 C127	403 157 1508 403 164 0204	CERAMIC 3P C 50V CERAMIC 0.1U Z 25V	C1881	403 164 0204	CERAMIC 0.1U Z 25V
C127	403 164 0204	CERAMIC 0.10 Z 25V CERAMIC 0.068U K 16V	C1883	403 164 0204	CERAMIC 0.1U Z 25V
C1301	403 164 0204	CERAMIC 0.000 K 10V	C1889	403 164 0204	CERAMIC 0.1U Z 25V
C1302	403 164 0204	CERAMIC 0.1U Z 25V	C1891	403 164 0204	CERAMIC 0.1U Z 25V
C1306	403 164 0204	CERAMIC 0.1U Z 25V	C1895 C1896	403 164 0204 401 105 7909	CERAMIC 0.1U Z 25V MT-GLAZE 0.000 ZA 1/16W
C131	403 307 7008	CERAMIC 0.068U K 16V	C1899	401 103 7909	CERAMIC 0.1U Z 25V
C132	403 307 7008	CERAMIC 0.068U K 16V	C2501	403 164 0204	CERAMIC 0.10 Z 25V
C1321	403 164 0204	CERAMIC 0.1U Z 25V	C2501	403 164 0204	CERAMIC 0.10 Z 25V
C133	403 307 7008	CERAMIC 0.068U K 16V	C2507	403 164 0204	CERAMIC 0.1U Z 25V
C1331	403 164 0204	CERAMIC 0.1U Z 25V	C2512	403 164 0204	CERAMIC 0.1U Z 25V
C1332	403 164 0204	CERAMIC 0.1U Z 25V	C2513	403 164 0204	CERAMIC 0.1U Z 25V
C1336	403 304 1801	ELECT 100U M 6.3V	C2514	403 164 0204	CERAMIC 0.1U Z 25V
C1338	403 373 7704 401 105 7909	ELECT 100U M 6.3V	C2521	403 164 0204	CERAMIC 0.1U Z 25V
C1338 C134	401 105 7909	MT-GLAZE 0.000 ZA 1/16W CERAMIC 1500P K 50V	C2522	403 164 0204	CERAMIC 0.1U Z 25V
C134	403 205 2808	CERAMIC 1300F K 30V CERAMIC 0.047U K 25V	C2523	403 164 0204	CERAMIC 0.1U Z 25V
C137	403 164 0204	CERAMIC 0.0470 K 25V	C2524	403 164 0204	CERAMIC 0.1U Z 25V
C139	403 281 5205	CERAMIC 0.22U Z 16V	C2525	403 164 0204	CERAMIC 0.1U Z 25V
C141	403 155 2101	CERAMIC 1500P K 50V	C2526 C2527	403 164 0204 403 164 0204	CERAMIC 0.1U Z 25V CERAMIC 0.1U Z 25V
C142	403 215 0900	CERAMIC 390P J 50V	C2527 C2531	403 164 0204	CERAMIC 0.1U Z 25V ELECT 100U M 16V
C143	403 155 1609	CERAMIC 33P J 50V	C2331	403 229 3308	ELECT 1000 M 16V
				100 000 0400	1000 F1 10V

Licotricari							
Key No.	Part No.	Description		Key No.	Part No.	Description	
C2532	403 164 0204	CERAMIC 0.1U	Z 25V	C381	403 215 2102	CERAMIC	8200P K 50V
C2533	403 164 0204	CERAMIC 0.1U	Z 25V	C382	403 280 0805	ELECT	330U M 6.3V
C2534	403 164 0204	CERAMIC 0.1U	Z 25V	C384	403 215 2102	CERAMIC	8200P K 50V
C2536	403 164 0204	CERAMIC 0.1U	Z 25V	C386	403 347 5507	POS-SOLID	470U M 4V
C2537	403 164 0204	CERAMIC 0.1U	Z 25V	C387	403 164 0204	CERAMIC	0.1U Z 25V
C2538	403 164 0204	CERAMIC 0.1U	Z 25V	C388	403 164 0204	CERAMIC	0.1U Z 25V
C2539	403 164 0204	CERAMIC 0.1U	Z 25V	C391	403 164 0204	CERAMIC	0.1U Z 25V
C302	403 164 0204	CERAMIC 0.1U	Z 25V	C392	403 175 0606	ELECT	100U M 6.3V
C303	403 164 0204	CERAMIC 0.1U	Z 25V	C393	403 215 2102	CERAMIC	8200P K 50V
C306	403 164 0204	CERAMIC 0.1U	Z 25V	C394	403 347 5507	POS-SOLID	470U M 4V
C307	403 164 0204	CERAMIC 0.1U	Z 25V	C396	403 164 0204	CERAMIC	0.1U Z 25V
C309	403 164 0204	CERAMIC 0.1U		C401	403 164 0204	CERAMIC	0.1U Z 25V
C311	403 164 0204	CERAMIC 0.1U		C402	403 215 2201	CERAMIC	0.01U K 50V
C312	403 164 0204	CERAMIC 0.1U		C411	403 149 9208	CERAMIC	0.01U Z 50V
C313	403 164 0204	CERAMIC 0.1U		C412	403 283 6309	CERAMIC	1U Z 10V
C314	403 164 0204	CERAMIC 0.1U		C413	403 149 9208	CERAMIC	0.01U Z 50V
C316	403 164 0204	CERAMIC 0.1U		C414	403 149 9208	CERAMIC	0.01U Z 50V
C317	403 164 0204	CERAMIC 0.1U		C416	403 164 0204	CERAMIC	0.1U Z 25V
C318	403 164 0204	CERAMIC 0.1U		C419	403 149 9208	CERAMIC	0.01U Z 50V
C319 C321	403 164 0204 403 164 0204	CERAMIC 0.1U CERAMIC 0.1U		C420 C421	403 378 3107 403 283 6309	CERAMIC CERAMIC	47U Z 6.3V 1U Z 10V
C322	403 164 0204	CERAMIC 0.10		C421	403 283 0309	CERAMIC	0.01U Z 50V
C322	403 164 0204	CERAMIC 0.10		C422	403 149 9208	CERAMIC	0.010 Z 50V 0.01U Z 50V
C324	403 164 0204	CERAMIC 0.1U		C424	403 149 9208	CERAMIC	0.010 Z 50V 0.01U Z 50V
C326	403 164 0204	CERAMIC 0.1U		C426	403 149 9208	CERAMIC	0.01U Z 50V
C327	403 164 0204	CERAMIC 0.1U		C427	403 149 9208	CERAMIC	0.01U Z 50V
C328	403 164 0204	CERAMIC 0.1U		C428	403 149 9208	CERAMIC	0.01U Z 50V
C329	403 164 0204	CERAMIC 0.1U	Z 25V	C429	403 149 9208	CERAMIC	0.01U Z 50V
C331	403 164 0204	CERAMIC 0.1U	Z 25V	C431	403 149 9208	CERAMIC	0.01U Z 50V
C332	403 164 0204	CERAMIC 0.1U	Z 25V	C432	403 149 9208	CERAMIC	0.01U Z 50V
C333	403 164 0204	CERAMIC 0.1U		C433	403 149 9208	CERAMIC	0.01U Z 50V
C337	403 164 0204	CERAMIC 0.1U		C434	403 149 9208	CERAMIC	0.01U Z 50V
C338	403 164 0204	CERAMIC 0.1U		C436	403 149 9208	CERAMIC	0.01U Z 50V
C339	403 139 7306	CERAMIC 18P		C437	403 149 9208	CERAMIC	0.01U Z 50V
C341 C343	403 139 7306 403 283 6309	CERAMIC 18P CERAMIC 1U		C438 C439	403 149 9208 403 149 9208	CERAMIC CERAMIC	0.01U Z 50V 0.01U Z 50V
C344	403 263 6309	CERAMIC 0.1U		C4591	403 149 9208	CERAMIC	0.010 Z 30V 0.1U Z 25V
C3501	403 164 0204	CERAMIC 0.1U		C4503	403 164 0204	CERAMIC	0.1U Z 25V
C3503	403 164 0204	CERAMIC 0.1U		C4504	403 164 0204	CERAMIC	0.10 Z 25V
C3504	403 164 0204	CERAMIC 0.1U		C4531	403 164 0204	CERAMIC	0.1U Z 25V
C3506	403 164 0204			C4532	403 378 3107	CERAMIC	47U Z 6.3V
C3507	403 229 3508	ELECT 100U	M 16V	C4533	403 164 0204	CERAMIC	0.1U Z 25V
	403 335 0408	ELECT 100U	M 16V	C4534	403 164 0204	CERAMIC	0.1U Z 25V
C352	403 149 9208	CERAMIC 0.01U		C4551	403 164 0204	CERAMIC	0.1U Z 25V
C353	403 149 9208	CERAMIC 0.01U		C4553	403 164 0204	CERAMIC	0.1U Z 25V
C3531	403 164 0204	CERAMIC 0.1U		C4554	403 164 0204	CERAMIC	0.1U Z 25V
C3533	403 164 0204	CERAMIC 0.1U		C4601	403 322 7809	ELECT	220U M 6.3V
C3534	403 164 0204	CERAMIC 0.1U		G4602	403 349 4706	ELECT	220U M 6.3V
C3536 C3537	403 164 0204 403 229 3508	CERAMIC 0.1U		C4603	403 280 1604 403 322 7809	ELECT	220U M 16V
C3537	403 229 3508	ELECT 100U ELECT 100U		C4604	403 349 4706	ELECT ELECT	220U M 6.3V 220U M 6.3V
C354	403 164 0204	CERAMIC 0.1U		C4651	403 229 3508	ELECT	100U M 16V
C3561	403 164 0204	CERAMIC 0.1U		01031	403 335 0408	ELECT	1000 H 16V
C3563	403 164 0204	CERAMIC 0.1U		C4652	403 229 3508	ELECT	100U M 16V
C3564	403 164 0204	CERAMIC 0.1U			403 335 0408	ELECT	100U M 16V
C3566	403 164 0204	CERAMIC 0.1U	Z 25V	C4653	403 229 3508	ELECT	100U M 16V
C3567	403 229 3508	ELECT 100U	M 16V		403 335 0408	ELECT	100U M 16V
	403 335 0408	ELECT 100U		C4654	403 229 3508	ELECT	100U M 16V
C360	403 113 3805	CERAMIC 1000P		l	403 335 0408	ELECT	100U M 16V
C371	403 283 6309	CERAMIC 1U		C491	403 149 9208	CERAMIC	0.01U Z 50V
C372	403 164 0204	CERAMIC 0.1U		C492	403 164 0204	CERAMIC	0.1U Z 25V
C373 C374	403 164 0204	CERAMIC 0.1U		C493	403 304 1801	ELECT	100U M 6.3V
C374	403 281 5205 403 113 4109	CERAMIC 0.22U CERAMIC 2200P		C494	403 373 7704 403 304 1801	ELECT ELECT	100U M 6.3V 100U M 6.3V
C376	403 113 4109	CERAMIC 2200P CERAMIC 0.1U			403 373 7704	ELECT	1000 M 6.3V
C378	403 280 0805	ELECT 330U		C501	403 164 0204	CERAMIC	0.1U Z 25V
C379	403 169 2807	CERAMIC 330P		C502	403 164 0204		0.1U Z 25V
				1			

Key No.	Part No.	Description	Key No.	Part No.	Description
C507	403 164 0204	CERAMIC 0.1U Z 25V	C7218	403 304 1801	ELECT 100U M 6.3V
C512	403 164 0204	CERAMIC 0.1U Z 25V		403 373 7704	ELECT 100U M 6.3V
C513	403 164 0204	CERAMIC 0.1U Z 25V	C7219	403 164 0204	CERAMIC 0.1U Z 25V
C514	403 164 0204	CERAMIC 0.1U Z 25V	C801	403 378 3107	CERAMIC 47U Z 6.3V
C521	403 164 0204	CERAMIC 0.1U Z 25V	C802	403 164 0204	CERAMIC 0.1U Z 25V
C522	403 164 0204	CERAMIC 0.1U Z 25V	C8101	403 164 0204	CERAMIC 0.1U Z 25V
C523 C524	403 164 0204 403 164 0204	CERAMIC 0.1U Z 25V CERAMIC 0.1U Z 25V	C8102 C8103	403 164 0204 403 379 6701	CERAMIC 0.1U Z 25V CERAMIC 10U K 16V
C525	403 164 0204	CERAMIC 0.10 Z 25V	C8103	403 379 6701	CERAMIC 100 K 10V CERAMIC 0.1U Z 25V
C526	403 164 0204	CERAMIC 0.1U Z 25V	C8121	403 164 0204	CERAMIC 0.1U Z 25V
C527	403 164 0204	CERAMIC 0.1U Z 25V	C8131	403 164 0204	CERAMIC 0.1U Z 25V
C5302	403 164 0204	CERAMIC 0.1U Z 25V	C8201	403 322 7809	ELECT 220U M 6.3V
C5303	403 316 5408	CERAMIC 1U K 10V		403 349 4706	ELECT 220U M 6.3V
C5304	403 283 6309	CERAMIC 1U Z 10V	C8202	403 164 0204	CERAMIC 0.1U Z 25V
C531	403 229 3508 403 335 0408	ELECT 100U M 16V ELECT 100U M 16V	C8203	403 322 7809 403 349 4706	ELECT 220U M 6.3V ELECT 220U M 6.3V
C532	403 333 0408	CERAMIC 0.1U Z 25V	C8204	403 164 0204	CERAMIC 0.1U Z 25V
C5321	403 164 0204	CERAMIC 0.1U Z 25V	C8205	403 164 0204	CERAMIC 0.1U Z 25V
C5322	403 372 7507	CERAMIC 2.2U K 6.3V	C8206	403 164 0204	CERAMIC 0.1U Z 25V
C5323	403 348 5803	CERAMIC 0.47U K 10V	C8207	403 164 0204	CERAMIC 0.1U Z 25V
C5324	403 364 5801	CERAMIC 1U K 10V	C8209	403 157 3809	CERAMIC 120P J 50V
C5326	403 348 5803	CERAMIC 0.47U K 10V	C8210	403 164 0204	CERAMIC 0.1U Z 25V
C5327 C5328	403 372 7507 403 364 5801	CERAMIC 2.2U K 6.3V CERAMIC 1U K 10V	C8211 C8212	403 164 0204 403 164 0204	CERAMIC 0.1U Z 25V CERAMIC 0.1U Z 25V
C5326	403 164 0204	CERAMIC 1U K 10V CERAMIC 0.1U Z 25V	C8212	403 164 0204	CERAMIC 0.1U Z 25V CERAMIC 0.1U Z 25V
C5331	403 157 3601	CERAMIC 0.10 Z 25V	C8213	403 145 9905	CERAMIC 0.10 Z 25V
C5332	403 164 0204	CERAMIC 0.1U Z 25V	C8216	403 205 2808	CERAMIC 0.047U K 25V
C5333	403 304 1801	ELECT 100U M 6.3V	C8217	403 164 0204	CERAMIC 0.1U Z 25V
	403 373 7704	ELECT 100U M 6.3V	C8218	403 145 9905	CERAMIC 22P J 50V
C534	403 164 0204	CERAMIC 0.1U Z 25V	C8219	403 205 2808	CERAMIC 0.047U K 25V
C5341	403 215 2201	CERAMIC 0.01U K 50V	C8221	403 164 0204	CERAMIC 0.1U Z 25V
C5342 C5343	403 205 7803 403 229 3508	TA-SOLID 2.2U M 16V ELECT 100U M 16V	C8222 C8223	403 145 9905 403 205 2808	CERAMIC 22P J 50V CERAMIC 0.047U K 25V
63343	403 335 0408	ELECT 1000 M 16V	C8224	403 203 2000	CERAMIC 0.0470 K 25V
C5344	403 164 0204	CERAMIC 0.1U Z 25V	C8226	403 283 2905	CERAMIC 0.082U K 16V
C5348	403 372 7507	CERAMIC 2.2U K 6.3V	C8227	403 215 2102	CERAMIC 8200P K 50V
C5352	403 164 0204	CERAMIC 0.1U Z 25V	C8228	403 164 0204	CERAMIC 0.1U Z 25V
C536	403 164 0204	CERAMIC 0.1U Z 25V	C8229	403 164 0204	CERAMIC 0.1U Z 25V
C5361	403 164 0204	CERAMIC 0.1U Z 25V	C8230	403 164 0204	CERAMIC 0.1U Z 25V
C537 C538	403 164 0204 403 164 0204	CERAMIC 0.1U Z 25V CERAMIC 0.1U Z 25V	C8231 C8232	403 164 0204 403 164 0204	CERAMIC 0.1U Z 25V CERAMIC 0.1U Z 25V
C539	403 164 0204		C8232	403 164 0204	
C5622	403 164 0204		C8251	403 164 0204	CERAMIC 0.1U Z 25V
C5623	403 304 1801	ELECT 100U M 6.3V	C8801	403 155 1609	CERAMIC 33P J 50V
	403 373 7704	ELECT 100U M 6.3V	C8802	403 155 1609	CERAMIC 33P J 50V
C5624	403 164 0204		C8803	403 164 0204	CERAMIC 0.1U Z 25V
C5627	403 304 1801 403 373 7704	ELECT 100U M 6.3V	C8804 C8806	403 155 1609 403 155 1609	CERAMIC 33P J 50V CERAMIC 33P J 50V
C5632	403 373 7704	ELECT 100U M 6.3V ELECT 100U M 6.3V	C8807	403 153 1609	CERAMIC 33P J 50V CERAMIC 0.1U Z 25V
63032	403 373 7704	ELECT 100U M 6.3V	C8851	403 164 0204	CERAMIC 0.1U Z 25V
C5633	403 304 1801	ELECT 100U M 6.3V	C8852	403 280 0805	ELECT 330U M 6.3V
	403 373 7704	ELECT 100U M 6.3V	C9402	403 164 0204	CERAMIC 0.1U Z 25V
C5635	403 164 0204	CERAMIC 0.1U Z 25V	C9403	403 164 0204	CERAMIC 0.1U Z 25V
C5641	403 280 1802	ELECT 100U M 25V	C9404	403 164 0204	CERAMIC 0.1U Z 25V
C5642	403 229 3508	ELECT 100U M 16V	C9406	403 164 0204	CERAMIC 0.1U Z 25V
C6201	403 335 0408 403 164 0204	ELECT 100U M 16V CERAMIC 0.1U Z 25V	C9407 C9408	403 164 0204 403 164 0204	CERAMIC 0.1U Z 25V CERAMIC 0.1U Z 25V
C6201	403 153 9300	CERAMIC 0.10 Z 25V CERAMIC 82P J 50V	C9409	403 164 0204	CERAMIC 0.10 Z 25V
C6204	403 322 7809	ELECT 220U M 6.3V	C9411	403 164 0204	CERAMIC 0.1U Z 25V
	403 349 4706	ELECT 220U M 6.3V	C9412	403 164 0204	CERAMIC 0.1U Z 25V
C6212	403 153 9300	CERAMIC 82P J 50V	C9413	403 164 0204	CERAMIC 0.1U Z 25V
C6222	403 153 9300	CERAMIC 82P J 50V	C9414	403 164 0204	CERAMIC 0.1U Z 25V
C6231	403 164 0204	CERAMIC 0.1U Z 25V	C9801	403 323 8805	CERAMIC 2.2U Z 16V
C6271	403 283 6309	CERAMIC 1U Z 10V	C9802	403 323 8805	CERAMIC 2.2U Z 16V
C6281 C7215	403 164 0204 403 304 1801	CERAMIC 0.1U Z 25V ELECT 100U M 6.3V	C9803 C9804	403 323 8805 403 323 8805	CERAMIC 2.2U Z 16V CERAMIC 2.2U Z 16V
0.213	403 373 7704		C9806	403 283 6309	
		22 2000 11 0.5V			

Key No.	Part No.	Description	Key No.	Part No.	Description
RESISTOR			RB9404	645 037 0663	R-NETWORK 22X4 0.063W
RB101	645 037 0670	R-NETWORK 47X4 0.063W		645 021 4943	R-NETWORK 22X4 1/16W
DD100	645 018 8930	R-NETWORK 47X4 1/16W	RB9406	645 037 0663 645 021 4943	R-NETWORK 22X4 0.063W
RB102	645 037 0670 645 018 8930	R-NETWORK 47X4 0.063W R-NETWORK 47X4 1/16W	RB9407	645 021 4943	R-NETWORK 22X4 1/16W R-NETWORK 22X4 0.063W
RB103	645 037 0670	R-NETWORK 47X4 1,10W	1657107	645 021 4943	R-NETWORK 22X4 1/16W
	645 018 8930	R-NETWORK 47X4 1/16W	RB9408	645 037 0663	R-NETWORK 22X4 0.063W
RB104	645 037 0670	R-NETWORK 47X4 0.063W		645 021 4943	R-NETWORK 22X4 1/16W
DD1401	645 018 8930	R-NETWORK 47X4 1/16W	RB9409	645 037 0663	R-NETWORK 22X4 0.063W
RB1401	645 037 0663 645 021 4943	R-NETWORK 22X4 0.063W R-NETWORK 22X4 1/16W	RB9411	645 021 4943 645 037 0663	R-NETWORK 22X4 1/16W R-NETWORK 22X4 0.063W
RB1402	645 037 0663	R-NETWORK 22X4 1/16W R-NETWORK 22X4 0.063W	KD9411	645 021 4943	R-NETWORK 22X4 0.003W
	645 021 4943	R-NETWORK 22X4 1/16W	RB9412	645 037 0663	R-NETWORK 22X4 0.063W
RB1403	645 037 0663	R-NETWORK 22X4 0.063W		645 021 4943	R-NETWORK 22X4 1/16W
	645 021 4943	R-NETWORK 22X4 1/16W	RB9413	645 037 0663	R-NETWORK 22X4 0.063W
RB1404	645 037 0663	R-NETWORK 22X4 0.063W	DD 0 4 1 4	645 021 4943	R-NETWORK 22X4 1/16W
RB1406	645 021 4943 645 037 0663	R-NETWORK 22X4 1/16W R-NETWORK 22X4 0.063W	RB9414	645 037 0663 645 021 4943	R-NETWORK 22X4 0.063W R-NETWORK 22X4 1/16W
KBI400	645 021 4943	R-NETWORK 22X4 0.003W	RB9416	645 037 0663	R-NETWORK 22X4 1710W
RB1407	645 037 0663	R-NETWORK 22X4 0.063W		645 021 4943	R-NETWORK 22X4 1/16W
	645 021 4943	R-NETWORK 22X4 1/16W	R101	401 105 0306	MT-GLAZE 10 JA 1/16W
RB1501	645 037 0656	R-NETWORK 0X4 0.063W	R102	401 105 0306	MT-GLAZE 10 JA 1/16W
DD1500	645 024 7477	R-NETWORK 0X4 1/16W	R103	401 105 0306	MT-GLAZE 10 JA 1/16W
RB1502	645 037 0656 645 024 7477	R-NETWORK 0X4 0.063W R-NETWORK 0X4 1/16W	R104 R109	401 105 5202 401 105 0405	MT-GLAZE 470 JA 1/16W MT-GLAZE 100 JA 1/16W
RB1503	645 037 0656	R-NETWORK 0X4 1/16W R-NETWORK 0X4 0.063W	R103	401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W
101303	645 024 7477	R-NETWORK 0X4 1/16W	R114	401 105 0405	
RB1504	645 037 0656	R-NETWORK 0X4 0.063W	R121	401 037 5004	MT-GLAZE 0.000 ZA 1/10W
	645 024 7477	R-NETWORK 0X4 1/16W	R123	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
RB2501	645 037 0656	R-NETWORK 0X4 0.063W	R128	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
DDGEGG	645 024 7477	R-NETWORK 0X4 1/16W	R1302	401 105 0603 645 049 0248	MT-GLAZE 10K JA 1/16W
RB2502	645 037 0656 645 024 7477	R-NETWORK 0X4 0.063W R-NETWORK 0X4 1/16W	R1306 R131	401 105 5103	IMPEDANCE,120 OHM P MT-GLAZE 47 JA 1/16W
RB2503	645 037 0656	R-NETWORK 0X4 0.063W	R1321	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
	645 024 7477	R-NETWORK 0X4 1/16W	R1322	401 105 0405	MT-GLAZE 100 JA 1/16W
RB2504	645 037 0656	R-NETWORK 0X4 0.063W	R1323	645 049 0293	IMPEDANCE, 220 OHM P
	645 024 7477	R-NETWORK 0X4 1/16W	R134	401 105 5103	MT-GLAZE 47 JA 1/16W
RB4531	645 037 4920 645 031 4070	R-NETWORK 3.3KX4 0.063W R-NETWORK 3.3KX4 1/16W	R136 R138	401 105 5103 401 105 7909	MT-GLAZE 47 JA 1/16W MT-GLAZE 0.000 ZA 1/16W
RB4532	645 021 0426	R-NETWORK 4.7KX4 0.063W	R1381	401 105 0405	MT-GLAZE 0.000 ZA 1/16W
		R-NETWORK 4.7KX4 1/16W	R1382	401 105 0405	
RB501	645 037 0656	R-NETWORK 0X4 0.063W	R1383	401 105 4106	MT-GLAZE 3.3K JA 1/16W
		R-NETWORK 0X4 1/16W	R1384	401 105 0603	
RB502		R-NETWORK 0X4 0.063W	R1386 R1387	401 105 0603 401 105 7909	
RB503		R-NETWORK 0X4 1/16W R-NETWORK 0X4 0.063W	R1389	401 105 7909	
10505	645 024 7477	R-NETWORK 0X4 1/16W	R1391	401 105 7909	
RB504	645 037 0656	R-NETWORK 0X4 0.063W	R1401	401 105 0306	MT-GLAZE 10 JA 1/16W
	645 024 7477		R1402	401 105 0306	MT-GLAZE 10 JA 1/16W
RB8201	645 037 0663	R-NETWORK 22X4 0.063W	R1403	401 105 0306	MT-GLAZE 10 JA 1/16W
RB8202	645 021 4943 645 037 0663	R-NETWORK 22X4 1/16W R-NETWORK 22X4 0.063W	R1404 R1406	401 105 0306 401 105 0306	MT-GLAZE 10 JA 1/16W MT-GLAZE 10 JA 1/16W
KB0ZUZ	645 037 0663	R-NETWORK 22X4 0.063W R-NETWORK 22X4 1/16W	R1400 R1407	401 105 0306	MT-GLAZE 10 JA 1/16W
RB8203		R-NETWORK 22X4 0.063W	R1409	401 105 0306	
	645 021 4943	R-NETWORK 22X4 1/16W	R141	401 105 0405	MT-GLAZE 100 JA 1/16W
RB8204	645 037 0663	R-NETWORK 22X4 0.063W	R1411	401 105 0306	MT-GLAZE 10 JA 1/16W
DDOOG	645 021 4943	R-NETWORK 22X4 1/16W	R1412	401 105 0306	
RB8206	645 037 0663 645 021 4943	R-NETWORK 22X4 0.063W R-NETWORK 22X4 1/16W	R1416 R1417	401 105 0306 401 105 0306	MT-GLAZE 10 JA 1/16W MT-GLAZE 10 JA 1/16W
RB8207	645 037 0663	R-NETWORK 22X4 1/10W R-NETWORK 22X4 0.063W	R1417	401 105 0306	
	645 021 4943	R-NETWORK 22X4 1/16W	R1419	401 105 0306	MT-GLAZE 10 JA 1/16W
RB9401	645 037 0663	R-NETWORK 22X4 0.063W	R142	401 105 0405	MT-GLAZE 100 JA 1/16W
	645 021 4943	R-NETWORK 22X4 1/16W	R1421	401 105 2607	MT-GLAZE 22 JA 1/16W
RB9402	645 037 0663	R-NETWORK 22X4 0.063W	R1422	401 105 2607	MT-GLAZE 22 JA 1/16W
RB9403	645 021 4943	R-NETWORK 22X4 1/16W R-NETWORK 22X4 0.063W	R1423 R1424	401 105 0306 401 105 0306	
1/12/4/12		R-NETWORK 22X4 0.063W R-NETWORK 22X4 1/16W	R1424 R1426	401 105 0306	
	010 021 4747	TO THE TOTAL DEAT I / TOW	1.110	101 103 0300	

Electrical Pa	arto Liot				
Key No.	Part No.	Description	Key No.	Part No.	Description
R1427	401 105 0306	MT-GLAZE 10 JA 1/16W	R1833	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1428	401 105 0306	MT-GLAZE 10 JA 1/16W	R1834	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1429	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R1836	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R143 R1432	401 105 0405 401 105 0306	MT-GLAZE 100 JA 1/16W MT-GLAZE 10 JA 1/16W	R1837 R1838	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R1432 R1433	401 105 0306	MT-GLAZE 10 JA 1/16W MT-GLAZE 10 JA 1/16W	R1840	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 10 JA 1/16W
R1437	401 105 0306	MT-GLAZE 10 JA 1/16W	R1841	401 105 0306	MT-GLAZE 10 JA 1/16W
R1438	401 105 0306	MT-GLAZE 10 JA 1/16W	R1842	401 105 0306	MT-GLAZE 10 JA 1/16W
R1439	401 105 0306	MT-GLAZE 10 JA 1/16W	R1843	401 105 0306	MT-GLAZE 10 JA 1/16W
R1442	401 105 0306	MT-GLAZE 10 JA 1/16W	R1844	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R1443	401 105 2607	MT-GLAZE 22 JA 1/16W	R1846	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R1444 R1446	401 105 2607 401 105 7909	MT-GLAZE 22 JA 1/16W MT-GLAZE 0.000 ZA 1/16W	R1847 R1848	401 105 5301 401 105 5301	MT-GLAZE 4.7K JA 1/16W MT-GLAZE 4.7K JA 1/16W
R1447	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 10 JA 1/16W	R1849	401 105 3301	MT-GLAZE 4.7K UA 1/16W MT-GLAZE 3.3K JA 1/16W
R1448	401 105 0306	MT-GLAZE 10 JA 1/16W	R1851	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R1449	401 105 0306	MT-GLAZE 10 JA 1/16W	R1852	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R1451	401 105 0306	MT-GLAZE 10 JA 1/16W	R1853	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R1452	401 105 0306	MT-GLAZE 10 JA 1/16W	R1861	401 105 5905	MT-GLAZE 560 JA 1/16W
R1453	401 105 0306	MT-GLAZE 10 JA 1/16W	R1863	401 105 0405	MT-GLAZE 100 JA 1/16W
R1456 R1457	401 105 0306 401 105 0306	MT-GLAZE 10 JA 1/16W MT-GLAZE 10 JA 1/16W	R1864 R1866	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R1457	401 105 0306	MT-GLAZE 10 JA 1/16W MT-GLAZE 10 JA 1/16W	R1867	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R1462	401 105 0306	MT-GLAZE 10 JA 1/16W	R1871	401 105 0603	MT-GLAZE 10K JA 1/16W
R1463	401 105 0306	MT-GLAZE 10 JA 1/16W	R1872	401 105 0306	MT-GLAZE 10 JA 1/16W
R1464	401 105 0306	MT-GLAZE 10 JA 1/16W	R1873	401 105 1105	MT-GLAZE 12K JA 1/16W
R1467	401 105 2607	MT-GLAZE 22 JA 1/16W	R1874	401 105 2508	MT-GLAZE 20K JA 1/16W
R1468	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R1877	401 105 0603	MT-GLAZE 10K JA 1/16W
R1469 R1471	401 105 2607 401 105 0405	MT-GLAZE 22 JA 1/16W MT-GLAZE 100 JA 1/16W	R1881 R1882	401 105 2706 401 105 2706	MT-GLAZE 220 JA 1/16W MT-GLAZE 220 JA 1/16W
R1471	401 105 0405	MT-GLAZE 100 SA 1/16W MT-GLAZE 1K JA 1/16W	R1884	401 105 2700	MT-GLAZE 220 0A 1/16W MT-GLAZE 0.000 ZA 1/16W
R1473	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R1886	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1501	401 105 0405	MT-GLAZE 100 JA 1/16W	R1887	401 105 0504	MT-GLAZE 1K JA 1/16W
R1502	401 105 0405	MT-GLAZE 100 JA 1/16W	R1888	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1503	401 105 0405	MT-GLAZE 100 JA 1/16W	R1889	401 105 0603	MT-GLAZE 10K JA 1/16W
R1504 R151	401 105 7909 401 105 0603	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 10K JA 1/16W	R1891 R1892	401 105 0603 401 105 5301	MT-GLAZE 10K JA 1/16W MT-GLAZE 4.7K JA 1/16W
R1512	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R1893	401 105 0405	MT-GLAZE 4.7K 0A 1/16W
R1513	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R1896	401 105 8005	MT-GLAZE 1M JA 1/16W
R1514	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R1897	401 105 0306	MT-GLAZE 10 JA 1/16W
R1516	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2501	401 105 0405	MT-GLAZE 100 JA 1/16W
R1517	401 105 0405	MT-GLAZE 100 JA 1/16W	R2502	401 105 0405	MT-GLAZE 100 JA 1/16W
R1518 R1519	401 105 0405	MT-GLAZE 100 JA 1/16W	R2503 R2504	401 105 0405 401 105 7909	MT-GLAZE 100 JA 1/16W
R1519	401 105 0405 401 105 7909	MT-GLAZE 100 JA 1/16W MT-GLAZE 0.000 ZA 1/16W	R2504 R2512	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R1521	401 105 0405	MT-GLAZE 0.000 ZA 1/10W	R2512	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1522	401 105 0405	MT-GLAZE 100 JA 1/16W	R2514	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1524	401 105 0405	MT-GLAZE 100 JA 1/16W	R2516	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1531	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2517	401 105 0405	MT-GLAZE 100 JA 1/16W
R1532	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2518	401 105 0405	MT-GLAZE 100 JA 1/16W
R1533 R1534	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W	R2519 R2521	401 105 0405 401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W
R1535	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2522	401 105 0405	MT-GLAZE 100 JA 1/16W
R1536	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2524	401 105 0405	MT-GLAZE 100 JA 1/16W
R1541	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2531	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1542	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2532	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1543	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2533	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1544 R1547	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W	R2534 R2535	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R1547	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W	R2536	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R1549	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R2541	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1811	401 105 0603	MT-GLAZE 10K JA 1/16W	R2542	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1812	401 105 0603	MT-GLAZE 10K JA 1/16W	R2543	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1813	401 105 0603	MT-GLAZE 10K JA 1/16W	R2544	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1814	401 105 0603	MT-GLAZE 10K JA 1/16W	R2547	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R1815 R1818	401 105 0603 401 105 0603	MT-GLAZE 10K JA 1/16W MT-GLAZE 10K JA 1/16W	R2548 R2549	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R1832	401 105 7909		R302	401 105 7305	MT-GLAZE 0.000 ZA 1/16W

Licotilicai i					
Key No.	Part No.	Description	Key No.	Part No.	Description
R303	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R413	401 105 7909	
R304	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R414	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R305 R306	401 105 0306 401 105 0306	MT-GLAZE 10 JA 1/16W MT-GLAZE 10 JA 1/16W	R416 R417	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R308	401 105 0306	MT-GLAZE 10 JA 1/16W MT-GLAZE 10 JA 1/16W	R417 R418	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R311	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R419	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R314	401 105 0603	MT-GLAZE 10K JA 1/16W	R421	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R316	401 105 4007	MT-GLAZE 330 JA 1/16W	R422	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R317	401 105 6506	MT-GLAZE 680 JA 1/16W	R423	401 105 0405	MT-GLAZE 100 JA 1/16W
R318	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R424	401 105 0405	MT-GLAZE 100 JA 1/16W
R320 R322	401 105 0504 401 105 7909	MT-GLAZE 1K JA 1/16W MT-GLAZE 0.000 ZA 1/16W	R425 R426	401 105 7909 401 105 0306	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 10 JA 1/16W
R324	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 10K JA 1/16W	R428	401 105 0300	MT-GLAZE 0.000 ZA 1/16W
R327	401 105 0603	MT-GLAZE 10K JA 1/16W	R429	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R329	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R431	401 105 2508	MT-GLAZE 20K JA 1/16W
R331	401 105 0306	MT-GLAZE 10 JA 1/16W	R432	401 113 4402	MT-GLAZE 75 JA 1/16W
R332	401 105 0306	MT-GLAZE 10 JA 1/16W	R433	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R333	401 105 0306	MT-GLAZE 10 JA 1/16W	R434	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R334 R336	401 105 0306 401 105 7909	MT-GLAZE 10 JA 1/16W MT-GLAZE 0.000 ZA 1/16W	R436 R438	401 105 0306 401 105 7909	MT-GLAZE 10 JA 1/16W MT-GLAZE 0.000 ZA 1/16W
R339	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R439	401 105 7305	MT-GLAZE 0.000 ZA 1/10W MT-GLAZE 10 JA 1/16W
R341	645 049 0293	IMPEDANCE, 220 OHM P	R4501	401 105 0405	MT-GLAZE 100 JA 1/16W
R342	401 105 0306	MT-GLAZE 10 JA 1/16W	R4502	401 105 0405	MT-GLAZE 100 JA 1/16W
R343	401 105 0306	MT-GLAZE 10 JA 1/16W	R4503	401 105 0306	MT-GLAZE 10 JA 1/16W
R3501	645 049 7230	IMPEDANCE, 1000 OHM P	R4511	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R3502	401 105 8104	MT-GLAZE 56K JA 1/16W	R4512	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R351 R353	401 105 7909 401 105 0702	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 100K JA 1/16W	R4513 R4516	401 105 7909 401 105 4106	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 3.3K JA 1/16W
R3531	645 049 7230	IMPEDANCE, 1000 OHM P	R4517	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R3532		MT-GLAZE 56K JA 1/16W	R4518	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R354	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4521	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R3561	645 049 7230	IMPEDANCE, 1000 OHM P	R4522	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R3562	401 105 8104	MT-GLAZE 56K JA 1/16W	R4523	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R358 R359	401 105 1501 401 105 5905	MT-GLAZE 1.5K JA 1/16W MT-GLAZE 560 JA 1/16W	R4531 R4532	401 105 0405 401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W
R361	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4536	401 105 0405	MT-GLAZE 0.000 ZA 1/16W
R362	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4537	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R364	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4541	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R366	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4546	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R367		MT-GLAZE 1K JA 1/16W	R4547	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R368 R371	401 105 0504 401 105 4700		R4548 R4549	401 105 5301 401 105 5301	- , , , , , , , , , , , , , , , , , , ,
R372	401 103 4700		R4549	401 105 3301	
R373		MT-GLAZE 39K JA 1/16W	R4552	401 105 7909	
R374	401 113 8301	MT-GLAZE 62K JA 1/16W	R4553	401 105 0603	MT-GLAZE 10K JA 1/16W
R376	401 113 6703	MT-GLAZE 9.1K JA 1/16W	R4554	401 105 4601	MT-GLAZE 3.9K JA 1/16W
R377	401 113 6703	MT-GLAZE 9.1K JA 1/16W	R4556	401 113 6604	MT-GLAZE 7.5K JA 1/16W
R378	401 113 6703	MT-GLAZE 9.1K JA 1/16W	R4557	401 113 6604	MT-GLAZE 7.5K JA 1/16W
R379 R381	401 113 6703 401 105 2508	MT-GLAZE 9.1K JA 1/16W MT-GLAZE 20K JA 1/16W	R4558 R4559	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R382	401 113 4204	MT-GLAZE 20K 0K 1/10W MT-GLAZE 51 JA 1/16W	R4601	401 105 0603	MT-GLAZE 10K JA 1/16W
R383	401 105 4007	MT-GLAZE 330 JA 1/16W	R4602	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R384	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R4603	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R386	401 113 6208	MT-GLAZE 3.6K JA 1/16W	R4606	401 276 4707	MT-GLAZE 0.000 ZA 1/3W
R387	401 105 2102	MT-GLAZE 18K JA 1/16W	R4652	401 105 0405	MT-GLAZE 100 JA 1/16W
R388 R389	401 105 4007 401 113 4204	MT-GLAZE 330 JA 1/16W MT-GLAZE 51 JA 1/16W	R4656 R4657	401 105 0306 401 105 0306	MT-GLAZE 10 JA 1/16W MT-GLAZE 10 JA 1/16W
R391	401 113 4204	MT-GLAZE 0.000 ZA 1/16W	R4658	401 105 0306	MT-GLAZE 10 JA 1/16W
R392	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R4659	401 105 0306	MT-GLAZE 10 JA 1/16W
R393	401 105 3802	MT-GLAZE 30K JA 1/16W	R4811	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R394	401 105 2102	MT-GLAZE 18K JA 1/16W	R4812	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R396	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4814	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R400 R401	645 050 2972 401 105 0306	IMPEDANCE,600 OHM P MT-GLAZE 10 JA 1/16W	R4816 R4817	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R401 R402	401 105 0306	MT-GLAZE 10 JA 1/16W MT-GLAZE 10 JA 1/16W	R4817 R4821	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 75 JA 1/3W
R403	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R4822	401 260 4102	MT-GLAZE 75 JA 1/3W
R412	401 105 7909		R491	401 102 7407	

Electrical P	arts list				
Key No.	Part No.	Description	Key No.	Part No.	Description
R492	401 102 7407	MT-GLAZE 10 JA 1W	R5641	401 105 0603	MT-GLAZE 10K JA 1/16W
R493	401 105 0405	MT-GLAZE 100 JA 1/16W	R5642	401 105 4106	MT-GLAZE 3.3K JA 1/16W
R501 R502	401 105 0405 401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W	R5643 R6201	401 105 5301 401 105 1402	MT-GLAZE 4.7K JA 1/16W MT-GLAZE 150 JA 1/16W
R502	401 105 0405	MT-GLAZE 100 JA 1/16W	R6201	401 105 1402	MT-GLAZE 130 JA 1/16W
R504	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6204	401 105 4502	MT-GLAZE 390 JA 1/16W
R512	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6207	401 105 0603	MT-GLAZE 10K JA 1/16W
R513	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6211	401 105 1402	MT-GLAZE 150 JA 1/16W
R514	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6213	401 105 5202	MT-GLAZE 470 JA 1/16W
R516	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6214	401 105 4502	MT-GLAZE 390 JA 1/16W
R517	401 105 0405	MT-GLAZE 100 JA 1/16W	R6217	401 105 0603	MT-GLAZE 10K JA 1/16W
R518 R519	401 105 0405 401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W	R6221 R6223	401 105 1402 401 105 5202	MT-GLAZE 150 JA 1/16W MT-GLAZE 470 JA 1/16W
R519	401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W	R6223 R6224	401 105 3202	MT-GLAZE 470 JA 1/16W MT-GLAZE 390 JA 1/16W
R522	401 105 0405	MT-GLAZE 100 JA 1/16W	R6227	401 105 0603	MT-GLAZE 10K JA 1/16W
R524	401 105 0405	MT-GLAZE 100 JA 1/16W	R6231	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R5301	401 037 5004	MT-GLAZE 0.000 ZA 1/10W	R6232	401 105 5400	MT-GLAZE 47K JA 1/16W
R5302	401 105 2805	MT-GLAZE 2.2K JA 1/16W	R6233	401 105 0504	MT-GLAZE 1K JA 1/16W
R5303	401 105 0504	MT-GLAZE 1K JA 1/16W	R6241	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R5304	401 105 8203	MT-GLAZE 68K JA 1/16W	R6242	401 105 5400	MT-GLAZE 47K JA 1/16W
R5306	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6243	401 105 0504	MT-GLAZE 1K JA 1/16W
R5308 R531	401 105 6605 401 105 7909	MT-GLAZE 6.8K JA 1/16W MT-GLAZE 0.000 ZA 1/16W	R6251 R6252	401 105 5301 401 105 5400	MT-GLAZE 4.7K JA 1/16W MT-GLAZE 47K JA 1/16W
R531	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 100 JA 1/16W	R6252 R6253	401 105 3400	MT-GLAZE 4/K JA 1/16W MT-GLAZE 1K JA 1/16W
R5312	401 105 0504	MT-GLAZE 1K JA 1/16W	R6271	401 105 0504	MT-GLAZE 1K JA 1/16W
R5313	401 105 0405	MT-GLAZE 100 JA 1/16W	R6281	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R5314	401 105 0504	MT-GLAZE 1K JA 1/16W	R6282	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R532	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6283	401 105 5301	MT-GLAZE 4.7K JA 1/16W
R5321	401 105 0405	MT-GLAZE 100 JA 1/16W	R6284	401 105 0405	MT-GLAZE 100 JA 1/16W
R5322	401 105 0405	MT-GLAZE 100 JA 1/16W	R6285	401 105 0405	MT-GLAZE 100 JA 1/16W
R5323 R5324	401 105 0405 401 105 8005	MT-GLAZE 100 JA 1/16W MT-GLAZE 1M JA 1/16W	R6286 R6287	401 105 0405 401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W
R5324	401 105 8005	MT-GLAZE 0.000 ZA 1/16W	R6288	401 105 0405	MT-GLAZE 100 GA 1/16W MT-GLAZE 100 JA 1/16W
R5331	401 105 4601	MT-GLAZE 3.9K JA 1/16W	R6289	401 105 0405	MT-GLAZE 100 JA 1/16W
R5332	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6291	401 105 0405	MT-GLAZE 100 JA 1/16W
R5333	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6292	401 105 0405	MT-GLAZE 100 JA 1/16W
R534	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R6801	401 105 5103	MT-GLAZE 47 JA 1/16W
R5341	401 105 6001	MT-GLAZE 5.6K JA 1/16W	R6802	401 105 5103	MT-GLAZE 47 JA 1/16W
R5342	401 113 5201 401 105 7909	MT-GLAZE 360 JA 1/16W	R6803	401 105 5103 401 105 5103	MT-GLAZE 47 JA 1/16W
R5343 R535	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W	R6806 R6807	401 105 5103	MT-GLAZE 47 JA 1/16W MT-GLAZE 47 JA 1/16W
R5351	401 105 7505	MT-GLAZE 0.000 ZA 1/10W MT-GLAZE 100 JA 1/16W	R6808	401 105 5103	MT-GLAZE 47 JA 1/16W
R5352	401 105 4106	MT-GLAZE 3.3K JA 1/16W	R6823	401 105 0306	MT-GLAZE 10 JA 1/16W
R5353	401 105 0405	MT-GLAZE 100 JA 1/16W	R6851	401 105 0306	MT-GLAZE 10 JA 1/16W
R5354	401 105 0405	MT-GLAZE 100 JA 1/16W	R6852	401 105 0306	MT-GLAZE 10 JA 1/16W
R5356	401 105 0405	MT-GLAZE 100 JA 1/16W	R6854	401 105 0306	MT-GLAZE 10 JA 1/16W
R5358	401 105 0603	MT-GLAZE 10K JA 1/16W	R6856	401 105 0306	MT-GLAZE 10 JA 1/16W
R5359 R536	401 105 0405 401 105 7909	MT-GLAZE 100 JA 1/16W MT-GLAZE 0.000 ZA 1/16W	R6857 R7201	401 105 0306 401 105 7909	MT-GLAZE 10 JA 1/16W MT-GLAZE 0.000 ZA 1/16W
R5361	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 100 JA 1/16W	R7201 R7231	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W
R5362	401 105 0405	MT-GLAZE 100 JA 1/16W	R7261	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5363	401 105 0405	MT-GLAZE 100 JA 1/16W	R7801	401 105 0603	MT-GLAZE 10K JA 1/16W
R5364	401 105 0405	MT-GLAZE 100 JA 1/16W	R7802	401 105 0603	MT-GLAZE 10K JA 1/16W
R541	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R7803	401 105 0603	MT-GLAZE 10K JA 1/16W
R542	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R7804	401 105 0603	MT-GLAZE 10K JA 1/16W
R543	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R7806	401 105 0603	MT-GLAZE 10K JA 1/16W
R544 R547	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W	R7807 R7821	401 105 7909 401 105 5301	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 4.7K JA 1/16W
R547	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W	R7821	401 105 5301	MT-GLAZE 4.7K JA 1/16W MT-GLAZE 10K JA 1/16W
R549	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R801	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5621	401 105 0504	MT-GLAZE 1K JA 1/16W	R802	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5622	401 105 0603	MT-GLAZE 10K JA 1/16W	R803	401 105 0603	MT-GLAZE 10K JA 1/16W
R5623	401 105 0504	MT-GLAZE 1K JA 1/16W	R804	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5626	401 276 4707	MT-GLAZE 0.000 ZA 1/3W	R807	401 105 0603	MT-GLAZE 10K JA 1/16W
R5631	401 105 0405	MT-GLAZE 100 JA 1/16W	R808	401 105 0603	MT-GLAZE 10K JA 1/16W
R5632	401 234 8105	MT-GLAZE 4.7 JA 1W	R8101	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R5633	401 234 8105	MT-GLAZE 4.7 JA 1W	R8102	401 105 0603	MT-GLAZE 10K JA 1/16W


	arto Liot				
Key No.	Part No.	Description	Key No.	Part No.	Description
R8103	401 105 0603	MT-GLAZE 10K JA 1/16W	R8852	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8104	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R8853	401 105 0405	MT-GLAZE 100 JA 1/16W
R8106		MT-GLAZE 0.000 ZA 1/16W	R8854	401 105 0504	
R8107	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R8855	401 105 5400	MT-GLAZE 47K JA 1/16W
R811	401 105 0603	MT-GLAZE 10K JA 1/16W	R8856	401 105 2904	MT-GLAZE 22K JA 1/16W
R8111	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R8857	401 105 0504	MT-GLAZE 1K JA 1/16W
R8112 R8113	401 105 5301 401 105 7909	MT-GLAZE 4.7K JA 1/16W MT-GLAZE 0.000 ZA 1/16W	R8858 R8859	401 105 2904 401 105 2904	MT-GLAZE 22K JA 1/16W MT-GLAZE 22K JA 1/16W
R8114	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W	R9401	401 105 2904	MT-GLAZE 22K JA 1/16W MT-GLAZE 0.000 ZA 1/16W
R8116		MT-GLAZE 4.7K JA 1/16W	R9402	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8117		MT-GLAZE 4.7K JA 1/16W	R9403	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8118	401 105 8005	MT-GLAZE 1M JA 1/16W	R9404	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8119	401 105 8005	MT-GLAZE 1M JA 1/16W	R9406	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8122	401 105 0603	MT-GLAZE 10K JA 1/16W	R9407	401 105 0603	MT-GLAZE 10K JA 1/16W
R8123	401 105 0603	MT-GLAZE 10K JA 1/16W	R9411	401 105 0603	MT-GLAZE 10K JA 1/16W
R8124	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R9412	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8131	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R9413	401 105 2607	MT-GLAZE 22 JA 1/16W
R8132	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R9414	401 105 2607	MT-GLAZE 22 JA 1/16W
R8133	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R9416	401 105 2607	MT-GLAZE 22 JA 1/16W
R8134	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	R9417	401 105 2607	MT-GLAZE 22 JA 1/16W
R8136		MT-GLAZE 4.7K JA 1/16W	R9418	401 105 2607	MT-GLAZE 22 JA 1/16W
R8137		MT-GLAZE 4.7K JA 1/16W	R9419	401 105 2607	MT-GLAZE 22 JA 1/16W
R8138 R8139	401 105 8005 401 105 8005	MT-GLAZE 1M JA 1/16W MT-GLAZE 1M JA 1/16W	R9421 R9422	401 105 0603 401 105 0603	MT-GLAZE 10K JA 1/16W MT-GLAZE 10K JA 1/16W
R8141	401 105 8005	MT-GLAZE 1M JA 1/16W	R9422 R9423	401 105 0603	MT-GLAZE 0.000 ZA 1/16W
R8142	401 105 8005	MT-GLAZE 1M JA 1/16W	R9424	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8143	401 105 0603	MT-GLAZE 10K JA 1/16W	R9425	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
R8144	401 105 0603	MT-GLAZE 10K JA 1/16W	R9802	401 105 0306	MT-GLAZE 10 JA 1/16W
R8151	401 105 8005	MT-GLAZE 1M JA 1/16W	R9803	401 105 0306	MT-GLAZE 10 JA 1/16W
R8152	401 105 8005	MT-GLAZE 1M JA 1/16W	R9807	401 105 0405	MT-GLAZE 100 JA 1/16W
R8161	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R9808	401 105 0603	MT-GLAZE 10K JA 1/16W
R8162	401 105 5301	MT-GLAZE 4.7K JA 1/16W	R9809	401 105 0405	MT-GLAZE 100 JA 1/16W
R8163	401 105 0405	MT-GLAZE 100 JA 1/16W	TRANSFORI	MFR	
R8164		MT-GLAZE 100 JA 1/16W	T371	405 139 7706	TR IMZ1A-T108
R8201	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	T372	405 139 7706	
R8202	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
R8203 R8204	401 105 7909 401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 0.000 ZA 1/16W	COIL		
R8211	401 105 7909	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 100 JA 1/16W	L121	645 050 2996	IMPEDANCE, 600 OHM P
R8212	401 105 0405	MT-GLAZE 100 JA 1/16W	L122	401 037 5004 645 049 6967	MT-GLAZE 0.000 ZA 1/10W
R8213		MT-GLAZE 100 JA 1/16W	L1301 L1302	645 049 6967	IMPEDANCE,600 OHM P IMPEDANCE,600 OHM P
R8214	401 105 7909		L1302	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R8216	401 105 7909		L1331	401 035 4108	MT-GLAZE 0.000 ZA 1/8W
R8217	401 105 5301	MT-GLAZE 4.7K JA 1/16W	L371	645 033 7949	INDUCTOR, 33U M
R8218		MT-GLAZE 4.7K JA 1/16W	L372	645 062 2854	INDUCTOR, 33U M
R8221	401 105 3307	MT-GLAZE 2.7K JA 1/16W	L5321	645 026 0964	INDUCTOR, 10U K
R8222	401 105 4403	MT-GLAZE 39 JA 1/16W	L5621	645 001 4512	INDUCTOR,10U K
R8223	401 105 5202	MT-GLAZE 470 JA 1/16W	L6201	645 026 0995	INDUCTOR,22U K
R8224	401 105 3109	MT-GLAZE 27 JA 1/16W	L6202	401 276 4707	MT-GLAZE 0.000 ZA 1/3W
R8251	401 105 0405	MT-GLAZE 100 JA 1/16W	L8201	645 026 0988	INDUCTOR, 2.2U M
R8252 R8253	401 105 0405 401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W	L8202	401 037 5004	MT-GLAZE 0.000 ZA 1/10W
R8291	645 049 0248	IMPEDANCE, 120 OHM P	L8203	401 037 5004	MT-GLAZE 0.000 ZA 1/10W
R8292	645 049 0248	IMPEDANCE, 120 OHM P	L8204	645 050 2996	IMPEDANCE,600 OHM P
R8293	401 105 5103	MT-GLAZE 47 JA 1/16W	DIODE		
R8294	401 105 5103	MT-GLAZE 47 JA 1/16W	D151	407 149 0807	DIODE 1SS355-TE-17
R8801	401 105 0306	MT-GLAZE 10 JA 1/16W	D301	407 149 0807	DIODE 1SS355-TE-17
R8802	401 105 0306	MT-GLAZE 10 JA 1/16W	D371		DIODE RB051L-40-TE25
R8803	401 105 0603	MT-GLAZE 10K JA 1/16W	D372		DIODE RB051L-40-TE25
R8804	401 105 0603	MT-GLAZE 10K JA 1/16W	D4811	407 209 1201	
R8808	401 105 0306	MT-GLAZE 10 JA 1/16W	D4812	407 209 1201	
R8809	401 105 0306	MT-GLAZE 10 JA 1/16W	D4813	407 209 1201	ZD UDZS-TE-176.2B
R8812	401 105 0603	MT-GLAZE 10K JA 1/16W	D4814	407 209 1201	
R8813	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	D491	407 149 0807	DIODE 199355-TE-17
R8819 R8820	401 260 4102	MT-GLAZE 75 JA 1/3W MT-GLAZE 75 JA 1/3W	D492 D5351	407 149 0807 407 149 0807	DIODE 1SS355-TE-17 DIODE 1SS355-TE-17
R8851	401 260 4102 401 105 0306		D5351		DIODE 1SS355-TE-17 DIODE 1SS355-TE-17
1.00001	101 103 0300	11 JUNU 10 UN 1/10W	20002	_010 0007	


Electrical Pa	arts List				
Key No.	Part No.	Description	Key No.	Part No.	Description
D5631	407 149 0807	DIODE 1SS355-TE-17	610 307 8939	ASSY,PWB,AV	M4KA 1AA0B10C4790A
D6804	407 149 0807 407 149 0807	DIODE 188355-TE-17	TRANSISTOR	•	
D6805 D6806	407 149 0807	DIODE 1SS355-TE-17 DIODE 1SS355-TE-17	Q1051	405 014 4509	TR 2SC2412K T146 R
D7801	407 149 0807	DIODE 1SS355-TE-17 DIODE 1SS355-TE-17	Q1031	405 014 4509	TR 2SC2412K T146 K
D7801	407 149 0807	DIODE 133335-TE-17 DIODE 1SS355-TE-17		405 014 4008	TR 2SC2812-L6-TB
D7803	407 149 0807	DIODE 1SS355-TE-17		405 015 8902	TR 2SC2812-L7-TB
D7804	407 149 0807	DIODE 1SS355-TE-17		405 163 1602	TR 2SC2812N-L6-TB0
D7806	407 149 0807	DIODE 1SS355-TE-17		405 163 1701	TR 2SC2812N-L7-TB0
D7807	407 149 0807	DIODE 1SS355-TE-17		405 173 9803	TR 2SC3928A1R
D7811	407 149 0807	DIODE 1SS355-TE-17		405 173 9902	TR 2SC3928A1S
D7812	407 149 0807	DIODE 1SS355-TE-17	Q1061	405 014 4509	TR 2SC2412K T146 R
D7813	407 149 0807	DIODE 1SS355-TE-17		405 014 4608	TR 2SC2412K T146 S
D7814	407 149 0807	DIODE 1SS355-TE-17		405 015 8704	TR 2SC2812-L6-TB
D7821	407 149 0807	DIODE 1SS355-TE-17		405 015 8902	TR 2SC2812-L7-TB
D8101	407 201 2701	DIODE RB051L-40-TE25		405 163 1602	TR 2SC2812N-L6-TB0
D8102	407 210 5601	DIODE RB500V-40-TE-17		405 163 1701	TR 2SC2812N-L7-TB0
D8103	407 201 2701	DIODE RB051L-40-TE25		405 173 9803	TR 2SC3928A1R TR 2SC3928A1S
D8851	407 209 1201 407 209 1201	ZD UDZS-TE-176.2B	Q1062	405 173 9902 405 014 4509	TR 2SC3928AIS TR 2SC2412K T146 R
D8852 D8853	407 209 1201	ZD UDZS-TE-176.2B DIODE 1SS355-TE-17	Q100Z	405 014 4509	TR 2SC2412K T146 R TR 2SC2412K T146 S
D8853	407 149 0807	DIODE ISS355-TE-17 DIODE ISS355-TE-17		405 014 4608	TR 2SC2412K T146 S TR 2SC2812-L6-TB
1 20034	10, 14, 000/	21022 100000 ID 1/		405 015 8704	TR 2SC2812-L7-TB
MISCELLAN				405 163 1602	TR 2SC2812N-L6-TB0
SW6801	645 026 2791	SWITCH, PUSH 1P-1TX1		405 163 1701	TR 2SC2812N-L7-TB0
SW6802	645 026 2791	SWITCH, PUSH 1P-1TX1		405 173 9803	TR 2SC3928A1R
SW6804	645 026 2791	SWITCH, PUSH 1P-1TX1		405 173 9902	TR 2SC3928A1S
SW6806	645 026 2791	SWITCH, PUSH 1P-1TX1	Q5201	405 134 5905	TR 2SA1037AK-T146-R
SW6807	645 026 2791	SWITCH, PUSH 1P-1TX1		405 147 2205	TR 2SA1037AK-S-T146
SW6809 SW6811	645 026 2791 645 026 2791	SWITCH, PUSH 1P-1TX1		405 002 0308	TR 2SA1037K T146 R
X101	645 034 6118	SWITCH, PUSH 1P-1TX1 OSC, CRYSTAL 20.250MHZ		405 002 0407	TR 2SA1037K T146 S
X1301	645 050 2323	OSC, CRYSTAL 25.000MHZ		405 002 6706	TR 2SA1179-M6-TB
X1895	645 046 1415	OSC, CERAMIC 4.00MHZ		405 002 6904	TR 2SA1179-M7-TB
X301	645 030 5863	OSC, CRISTAL, 14.318MHZ		405 163 1503	TR 2SA1179N-M6-TB
X5341	645 053 7677	OSC, CERAMIC 503.0KHZ		405 163 2708 405 173 9605	TR 2SA1179N-M7-TB
				405 173 9605	TR 2SA1235A1E TR 2SA1235A1F
610 307 890	8 ASSY,PWB,R/0	C M4KA 1AA0B10C4780B	Q5202	405 173 9704	TR 2SA1233AIF TR 2SA1037AK-T146-R
CAPACITOR	•		Q3202	405 147 2205	TR 2SA1037AK-S-T146
C2801	403 283 6309	CERAMIC 1U Z 10V		405 002 0308	TR 2SA1037K T146 R
C2801	403 283 6509			405 002 0407	TR 2SA1037K T146 S
C2803	403 378 3107			405 002 6706	TR 2SA1179-M6-TB
C2804	403 378 3107			405 002 6904	TR 2SA1179-M7-TB
				405 163 1503	TR 2SA1179N-M6-TB
RESISTOR				405 163 2708	TR 2SA1179N-M7-TB
R2801	401 105 5103			405 173 9605	
R2802	401 105 0405	MT-GLAZE 100 JA 1/16W		405 173 9704	
MISCELLAN	IEOUS		Q5203	405 014 4509	
A2811		UNIT, REMOCON RECEIVER		405 014 4608	
				405 015 8704	
610 307 891	5 ASSY,PWB,SE	NSOR M4KA 1AA0B10C4780C		405 015 8902 405 163 1602	
INTEGRATE	D CIRCUIT			405 163 1602	
IC8821		IC LM76CHMX-5		405 163 1701	TR 2SC2012N-L7-1BU
100021	407 401 00UZ	IC DM / OCUMY - 2		405 173 9803	
CAPACITOR	₹		Q5204	405 173 5502	
C8821	403 155 1609		~	405 147 2205	
C8822	403 155 1609			405 002 0308	
C8823	403 164 0204			405 002 0407	
C8824	403 205 7803	TA-SOLID 2.2U M 16V		405 002 6706	TR 2SA1179-M6-TB
RESISTOR				405 002 6904	
R8821	401 105 0306	MT-GLAZE 10 JA 1/16W		405 163 1503	
R8822	401 105 0306			405 163 2708	
R8823	401 105 0603	MT-GLAZE 10K JA 1/16W		405 173 9605	
R8827	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	05006	405 173 9704	
R8831	401 105 0405	MT-GLAZE 100 JA 1/16W	Q5206	405 134 5905	
				405 147 2205	TR 2SA1037AK-S-T146


Key No.	Part No.	Description	Key No.	Part No.	Description
	405 002 0308	TR 2SA1037K T146 R	C5207	403 355 9900	CERAMIC 2.2U K 10V
	405 002 0308	TR 2SA1037K T146 K TR 2SA1037K T146 S	C5207 C5208	403 355 9900	CERAMIC 2.20 K 10V CERAMIC 1U Z 10V
	405 002 6706	TR 2SA1179-M6-TB	C5209	403 298 9609	CERAMIC 0.1U K 16V
	405 002 6904	TR 2SA1179-M7-TB	C5210	403 215 2201	CERAMIC 0.01U K 50V
	405 163 1503	TR 2SA1179N-M6-TB	C5211	403 323 1301	CERAMIC 0.47U Z 10V
	405 163 2708	TR 2SA1179N-M7-TB	C5216	403 207 0307	CERAMIC 1U Z 16V
	405 173 9605	TR 2SA1235A1E	C5217	403 229 3508	ELECT 100U M 16V
Q5207	405 173 9704 405 134 5905	TR 2SA1235A1F TR 2SA1037AK-T146-R	C5218 C5219	403 207 0307 403 207 0307	CERAMIC 1U Z 16V CERAMIC 1U Z 16V
Q3207	405 134 3905	TR 2SA1037AK-S-T146	C5219	403 283 6309	CERAMIC 10 Z 10V
	405 002 0308	TR 2SA1037K T146 R	C5222	403 283 6309	CERAMIC 1U Z 10V
	405 002 0407	TR 2SA1037K T146 S	C5223	403 304 1801	ELECT 100U M 6.3V
	405 002 6706	TR 2SA1179-M6-TB	C5231	403 304 1801	ELECT 100U M 6.3V
	405 002 6904	TR 2SA1179-M7-TB	C5232	403 364 5801	CERAMIC 1U K 10V
	405 163 1503	TR 2SA1179N-M6-TB	C5233	403 304 1801	ELECT 100U M 6.3V
	405 163 2708 405 173 9605	TR 2SA1179N-M7-TB TR 2SA1235A1E	C5234 C5236	403 364 5801 403 304 1801	CERAMIC 1U K 10V ELECT 100U M 6.3V
	405 173 9704	TR 2SA1235A1E	C5237	403 364 5801	CERAMIC 1U K 10V
Q5208	405 014 4509	TR 2SC2412K T146 R	C5261	403 283 6309	CERAMIC 1U Z 10V
_	405 014 4608	TR 2SC2412K T146 S	C5262	403 298 9609	CERAMIC 0.1U K 16V
	405 015 8704	TR 2SC2812-L6-TB	C5263	403 355 9900	CERAMIC 2.2U K 10V
	405 015 8902	TR 2SC2812-L7-TB	RESISTOR		
	405 163 1602	TR 2SC2812N-L6-TB0	R1001	401 105 0504	MT-GLAZE 1K JA 1/16W
	405 163 1701 405 173 9803	TR 2SC2812N-L7-TB0 TR 2SC3928A1R	R1002	401 105 5400	MT-GLAZE 47K JA 1/16W
	405 173 9803	TR 2SC3928A1S	R1003	401 037 5004	MT-GLAZE 0.000 ZA 1/10W
Q5261	405 134 5905	TR 2SA1037AK-T146-R	R1004	401 105 1006	MT-GLAZE 1.2K JA 1/16W
	405 147 2205	TR 2SA1037AK-S-T146	R1021	401 105 0306	MT-GLAZE 10 JA 1/16W
	405 002 0308	TR 2SA1037K T146 R	R1022	401 105 0306 401 260 4102	MT-GLAZE 10 JA 1/16W MT-GLAZE 75 JA 1/3W
	405 002 0407	TR 2SA1037K T146 S	R1051 R1053	401 200 4102	MT-GLAZE 75 JA 1/3W MT-GLAZE 15K JA 1/16W
	405 002 6706	TR 2SA1179-M6-TB	R1054	401 105 1501	MT-GLAZE 1.5K JA 1/16W
	405 002 6904 405 163 1503	TR 2SA1179-M7-TB TR 2SA1179N-M6-TB	R1057	401 105 0405	MT-GLAZE 100 JA 1/16W
	405 163 2708	TR 2SA1179N-M7-TB	R1060	401 105 0405	MT-GLAZE 100 JA 1/16W
	405 173 9605	TR 2SA1235A1E	R1061	401 105 0603	MT-GLAZE 10K JA 1/16W
	405 173 9704	TR 2SA1235A1F	R1062	401 260 4102	MT-GLAZE 75 JA 1/16W
Q5262	405 014 4509	TR 2SC2412K T146 R	R1064 R1065	401 105 6605 401 105 0405	MT-GLAZE 6.8K JA 1/16W MT-GLAZE 100 JA 1/16W
	405 014 4608	TR 2SC2412K T146 S	R1066	401 105 0405	MT-GLAZE 1.5K JA 1/16W
	405 015 8704 405 015 8902	TR 2SC2812-L6-TB TR 2SC2812-L7-TB	R1067	401 260 4102	MT-GLAZE 75 JA 1/3W
	405 013 8902	TR 2SC2812N-L6-TB0	R1069	401 105 0504	MT-GLAZE 1K JA 1/16W
		TR 2SC2812N-L7-TB0	R1071	401 105 1501	MT-GLAZE 1.5K JA 1/16W
	405 173 9803	TR 2SC3928A1R	R1072	401 105 0405	
	405 173 9902	TR 2SC3928A1S	R1081 R2041	401 105 0405 401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W
INTEGRATE	D CIRCUIT		R2041 R2051	401 105 0405	MT-GLAZE 100 JA 1/16W MT-GLAZE 100 JA 1/16W
IC5201	409 530 7204	IC AN5870SB	R2052	401 105 0405	MT-GLAZE 100 JA 1/16W
IC5241	409 395 5902	IC TC7SH00FU-(TE85L)	R5200	401 105 0405	MT-GLAZE 100 JA 1/16W
CAPACITOR	1		R5201	401 260 4102	MT-GLAZE 75 JA 1/3W
C1001	403 164 0204	CERAMIC 0.1U Z 25V	R5202	401 105 4403	MT-GLAZE 39 JA 1/16W
C1008	403 164 0204	CERAMIC 0.1U Z 25V	R5203 R5204	401 260 4102 401 105 4403	MT-GLAZE 75 JA 1/3W MT-GLAZE 39 JA 1/16W
C1009	403 164 0204	CERAMIC 0.1U Z 25V	R5204	401 105 4405	MT-GLAZE 100 JA 1/16W
C1052	401 035 4108	MT-GLAZE 0.000 ZA 1/8W	R5206	401 260 4102	MT-GLAZE 75 JA 1/3W
C1061	403 164 0204	CERAMIC 0.1U Z 25V	R5207	401 105 4403	MT-GLAZE 39 JA 1/16W
C1063 C1064	401 105 7909 403 233 3808	MT-GLAZE 0.000 ZA 1/16W	R5208	401 260 4102	MT-GLAZE 75 JA 1/3W
C1064 C1066	403 233 3808	CERAMIC 10P C 50V MT-GLAZE 0.000 ZA 1/16W	R5209	401 260 4102	MT-GLAZE 75 JA 1/3W
C1000	403 164 0204	CERAMIC 0.1U Z 25V	R5210	401 105 0405	MT-GLAZE 100 JA 1/16W
C1082	403 304 1801	ELECT 100U M 6.3V	R5211 R5213	401 260 4102 401 105 0405	MT-GLAZE 75 JA 1/3W MT-GLAZE 100 JA 1/16W
C1083	403 164 0204	CERAMIC 0.1U Z 25V	R5214	401 105 0405	MT-GLAZE 0.000 ZA 1/16W
C1084	403 304 1801	ELECT 100U M 6.3V	R5215	401 105 0603	MT-GLAZE 10K JA 1/16W
C2041	403 164 0204	CERAMIC 0.1U Z 25V	R5217	401 105 0405	MT-GLAZE 100 JA 1/16W
C5201 C5202	403 355 9900 403 355 9900	CERAMIC 2.2U K 10V CERAMIC 2.2U K 10V	R5218	401 105 7909	MT-GLAZE 0.000 ZA 1/16W
C5202 C5203	403 355 9900	CERAMIC 2.20 K 10V CERAMIC 2.2U K 10V	R5219	401 105 5202	MT-GLAZE 470 JA 1/16W
C5204	403 355 9900	CERAMIC 2.2U K 10V	R5221 R5222	401 105 1501 401 105 0603	MT-GLAZE 1.5K JA 1/16W MT-GLAZE 10K JA 1/16W
C5206	403 355 9900		11,222	±01 100 0003	TO UA 1/10W


<u>Electrical Pa</u>	arto Liot				
Key No.	Part No.	Description	Key No.	Part No.	Description
R5223	401 105 6001	MT-GLAZE 5.6K JA 1/16W	D2041	407 209 1201	ZD UDZS-TE-176.2B
R5224	401 105 0405	MT-GLAZE 100 JA 1/16W	MISCELLAN	EOUS	
R5225	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	K10A	645 054 0226	SOCKET, DVI 29P
R5226 R5227	401 105 0405 401 105 5202	MT-GLAZE 100 JA 1/16W MT-GLAZE 470 JA 1/16W	K10B	645 055 5664	JACK,RCA-3
R5227	401 105 5202	MT-GLAZE 470 JA 1/16W MT-GLAZE 560 JA 1/16W	K10E	610 010 3689	JACK,RCA
R5229	401 105 1006	MT-GLAZE 1.2K JA 1/16W	K10F	610 010 8295	SOCKET, DIN 4P
R5230	401 105 1501	MT-GLAZE 1.5K JA 1/16W	K100G	645 049 6653	TERMINAL
R5231	401 105 0504	MT-GLAZE 1K JA 1/16W	K20B SC1001	645 048 6739 645 055 3202	SOCKET, DIN 8P SURGE-ABSORBER
R5232	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	SC1001 SC1002	645 055 3202	SURGE-ABSORBER
R5234	401 105 2805	MT-GLAZE 2.2K JA 1/16W	SC1003	645 055 3202	SURGE-ABSORBER
R5236 R5237	401 105 7909 401 105 0504	MT-GLAZE 0.000 ZA 1/16W MT-GLAZE 1K JA 1/16W	SC1004	645 055 3202	SURGE-ABSORBER
R5237	401 105 0304	MT-GLAZE 0.000 ZA 1/16W	SC1006	645 055 3202	SURGE-ABSORBER
R5239	401 105 0504	MT-GLAZE 1K JA 1/16W	SC1007	645 055 3202	SURGE-ABSORBER
R5240	401 105 1501		SC1008	645 055 3202	SURGE-ABSORBER
R5241	401 105 5905	MT-GLAZE 560 JA 1/16W	SC1009	645 055 3202	SURGE-ABSORBER
R5242	401 105 1006	MT-GLAZE 1.2K JA 1/16W	SC1011 SC1012	645 055 3202 645 055 3202	SURGE-ABSORBER
R5243	401 105 0504	MT-GLAZE 1K JA 1/16W	SC1012 SC1051	645 055 3202	SURGE-ABSORBER SURGE-ABSORBER
R5244	401 105 7909	MT-GLAZE 0.000 ZA 1/16W	SC1061	645 055 3202	SURGE-ABSORBER
R5245 R5246	401 105 1501 401 105 5905	MT-GLAZE 1.5K JA 1/16W MT-GLAZE 560 JA 1/16W	SC1062	645 055 3202	SURGE-ABSORBER
R5247	401 105 3905	MT-GLAZE	SC2051	645 055 3202	SURGE-ABSORBER
R5248	401 260 8407	MT-GLAZE 22 JA 1/3W	SC2052	645 055 3202	SURGE-ABSORBER
R5249	401 035 4306	MT-GLAZE 10 JA 1/8W	SW2041	645 042 8104	SWITCH, PUSH 1P-1TX1
R5251	401 105 0603	MT-GLAZE 10K JA 1/16W	610 307 894	6 ASSY.PWB.LE	D M4KA 1AA0B10C4790B
R5252	401 105 0603	MT-GLAZE 10K JA 1/16W		· · · · · · · · · · · · · · · · · · ·	
R5261	401 105 0504	MT-GLAZE 1K JA 1/16W	TRANSISTO	R	
R5262	401 105 3000	MT-GLAZE 220K JA 1/16W	Q2861	405 014 4509	
R5263 R5264	401 105 7404 401 105 0405	MT-GLAZE 8.2K JA 1/16W MT-GLAZE 100 JA 1/16W		405 014 4608	
R5265	401 105 0405	MT-GLAZE 1.2K JA 1/16W		405 015 8704 405 015 8902	TR 2SC2812-L6-TB TR 2SC2812-L7-TB
R5266	401 105 0504	MT-GLAZE 1K JA 1/16W		405 163 1602	TR 2SC2812-L7-1B
0011				405 163 1701	TR 2SC2812N-L7-TB0
COIL	645 050 2400	ETIMED EMT 25DE		405 173 9803	TR 2SC3928A1R
L1001 L1002	645 059 2409 645 059 2409	FILTER,EMI 35PF FILTER,EMI 35PF		405 173 9902	TR 2SC3928A1S
L1002	645 059 2416	FILTER, EMI 18PF	Q2862	405 014 4509	TR 2SC2412K T146 R
L1007	645 059 2416	FILTER, EMI 18PF		405 014 4608	TR 2SC2412K T146 S
L1008	645 059 2416	FILTER, EMI 18PF		405 015 8704 405 015 8902	TR 2SC2812-L6-TB TR 2SC2812-L7-TB
L1031		FILTER, EMI 18PF		405 015 8902	TR 2SC2812-L7-TB TR 2SC2812N-L6-TB0
L1032		FILTER, EMI 18PF		405 163 1701	
L1033		FILTER, EMI 18PF		405 173 9803	
L1052 L1061	401 035 4108	FILTER,EMI 100MHZ MT-GLAZE 0.000 ZA 1/8W		405 173 9902	TR 2SC3928A1S
L1062		FILTER, EMI 100MHZ	Q2863	405 014 4509	TR 2SC2412K T146 R
L1063	401 035 4108	· · · · · · · · · · · · · · · · · · ·		405 014 4608	
L1064	645 059 2386	FILTER, EMI 100MHZ		405 015 8704	
L1081	645 001 4512	INDUCTOR,10U K		405 015 8902 405 163 1602	
L2051		FILTER, EMI 20MHZ		405 163 1701	
L2052	645 059 2393	FILTER, EMI 20MHZ		405 173 9803	
DIODE				405 173 9902	
D1001	407 209 4509	ZD UDZS-TE-176.8B	Q2864	405 134 5905	
D1002	407 209 4509			405 147 2205	
D1003	407 209 1201			405 002 0308	
D1004	407 209 1201			405 002 0407 405 002 6706	
D1005 D1006	407 209 1201 645 055 3202	ZD UDZS-TE-176.2B SURGE-ABSORBER		405 002 6706	
D1000	645 055 3202	SURGE-ABSORBER		405 163 1503	
D1007	645 055 3202	SURGE-ABSORBER		405 163 2708	
D1031	407 209 4509			405 173 9605	TR 2SA1235A1E
D1032	407 209 4509	ZD UDZS-TE-176.8B		405 173 9704	TR 2SA1235A1F
D1033	407 209 4509	ZD UDZS-TE-176.8B	CAPACITOR	1	
D1034	407 209 4509	ZD UDZS-TE-176.8B	C2861	403 164 0204	CERAMIC 0.1U Z 25V
D1036	407 209 4509	ZD UDZS-TE-176.8B	C2862	403 164 0204	
D1037 D1061	407 209 4509 407 221 7106	ZD UDZS-TE-176.8B ZENER DIODE UDZS-TE-1712B			
דפחדת	401 441 /106	TEMEN DIONE ONTO-IF-1/17R	RESISTOR		


Electrical Fa					
Key No.	Part No.	Description	Key No.	Part No.	Description
R2862	401 105 0504				
R2864 R2866	401 105 5301 401 105 0504				
R2868	401 105 0304				
R2869	401 105 4502				
R2872	401 105 6506				
R2874	401 105 5301				
R2876	401 105 0504	MT-GLAZE 1K JA 1/16W			
R2878	401 105 0504	MT-GLAZE 1K JA 1/16W			
R2891	401 105 5301	MT-GLAZE 4.7K JA 1/16W			
DIODE					
D2861	407 209 7500	LED SML-210YT T86 L			
D2862	407 203 7803	LED SML-210LT T86 M			
D2863		LED SML-521MUW T86			
D6803	407 149 0807	DIODE 1SS355-TE-17			
MISCELLAN	EOUS				
SW6808		SWITCH, PUSH 1P-1TX1			
610 207 905					
010 307 8953	S ASST,PWB,DC	OOR SW M4K 1AA0B10C4790C			
RESISTOR					
R8851	401 105 7909	MT-GLAZE 0.000 ZA 1/16W			
MISCELLAN	FOLIS				
SW8801		SWITCH, MICRO 1P-2T			
610 307 8960	0 ASSY,PWB,LA	MP SW M4KA 1AA0B10C4790D			
MISCELLAN	EOUS				
∆ sw8803		SWITCH, PUSH 2P-2TX3			
610 308 8013	3 ASSY,PWB,INI	LET M4KA 1AA0B10C4800A			
MISCELLAN	FOUS				
Δ _{F601}	423 022 2102	FUSE 250V 4A			
△ K601					
		SOCKET, INLET AC 3P			
△ SW601	645 055 6661	SWITCH, POWER 2P-2TX2			
610 308 8020	O ASSY,PWB,FIL	TER M4KA 1AA0B10C4800B			
CAPACITOR	•				
A		NET DOT 11 DOT 11 OFFI			
△ C611	404 094 3808	MT-POLYEST 0.22U K 275V			
△ C612	404 094 3808				
△ C613	404 094 3808				
△ C614	404 094 3808	MT-POLYEST 0.22U K 275V			
△ C616	404 073 3904	CERAMIC 1000P K 250V			
△ C617	404 073 3904	CERAMIC 1000P K 250V			
RESISTOR					
R611	401 008 8607	CARBON 220K JA 1/2W			
	_01 000 0007	22011 011 1,200			
VARISTOR					
△ VA611	408 018 9808	VARISTOR ENC471D-14AS			
COIL					
△ L611	645 061 7522	LINE FILTER			
△ L611		LINE FILTER			
— T0T5	040 UOT 1277	DIME LINIEK			















See Electrical Parts List.



Key No.	Part No.	Description	Key No.	Part No.	Description
CABINET	PARTS		OPTICAL	PARTS	
No.1		CABINET FRONT SERVICE-M4KA	No.61		LENS, CONDENSER (GV)
	(Included No.1-a	and No.1-b.)	No.62	610 312 7989	ASSY,LCD PNL/PSM -M4KA
No.1-a	610 309 7657	DEC FRONT-M4KA		(Included from N	lo.62-a to No.62-e.)
No.1-b	610 309 4977	DEC INLAY FRONT-M4KA	No.62-a	645 064 1213	POLARIZED GLASS(OUT/R)0.7
No.2	610 312 8764	CABINET BOTTOM SERVICE-M4	No.62-b	645 063 4376	POLARIZED GLASS(OUT/B)0.7
No.3	610 312 8740	CABINET TOP SERVICE-M4KA	No.62-c	645 065 2523	POLARIZED GLASS(OUT/G)
No.4	610 308 8730	PANEL LMP-M4KA	No.62-d	645 063 4352	OPTICAL FILTER (WV-SF)B
No.5	610 308 8754	PANEL FILTER-M4KA	No.62-e	645 063 4345	OPTICAL FILTER (WV-SF)G
No.6	610 309 5134	PANEL AV-M4KA	No.63	645 057 5808	LENS, CONDENSER(R)
No.7	610 308 8006	ASSY, BUTTON POWER-M4KA	No.64	645 044 2452	ASSY, PRISM(PBS)
No.8	610 308 8174	BUTTON SELECT-M4KA	No.65	645 041 5029	LENS, CONDENSER (OUT)
No.9	610 308 8471	DEC INLAY LED-M4KA	No.66	645 041 5043	LENS, CONDENSER(B)
No.10	610 309 7671	DEC AV SHEET-M4KA	No.67	645 041 5050	LENS, RELAY(IN)
No.11	610 309 7527	COMPL, JOINT DOOR DUMPER L	No.68	645 041 5067	LENS, RELAY(OUT)
No.12	610 309 7534	COMPL, JOINT DOOR DUMPER R	No.69	645 056 0439	LENS, INTEGRATOR (IN)
No.13	610 309 7565	COMPL, STAND LEG L-M4KA	No.70	645 056 0446	LENS, INTEGRATOR (OUT)
No.14 No.15	610 309 7572 610 310 2429	COMPL, STAND LEG R-M4KA SPACER LEG-M4KA	No.71 No.72	645 063 0309 645 041 5494	LENS, PROJECTION MIRROR(R)
No.16	610 310 2429	STOPPER LID-M4JA	No.72	645 041 5500	MIRROR(R)
No.17	645 063 7414	BADGE, SANYO*26.2X5.7L26.0	No.74	645 044 0526	OPTICAL FILTER (RG)
No.18	610 312 0249	COMPLE, FILTER-M4KA	No.75	645 056 0453	OPTICAL FILTER (NG) OPTICAL FILTER (UV CUT)
No.19	610 311 3449	ASSY, DOOR-M4KA	No.76	645 056 0590	POLARIZED GLASS(OUT/R)0.7
No.20	610 308 8433	COVER DUCT BTM-M4KA	No.77	645 056 0613	POLARIZED GLASS(OUT/B)0.7
No.21	610 312 9532	COVER DUCT TOP-M4KA	No.78	645 063 4369	POLARIZED GLASS(IN/G)0.7
No.22	610 309 0122	COVER DUCT EXIT LMP-M4KA	No.79	645 044 1011	DICHROIC MIRROR (G)
No.23	610 309 7640	COVER FAN SLIT-M4KA	No.80	645 056 0477	DICHROIC MIRROR (R)
No.24	610 310 1927	COVER DUCT EXIT POW-M4KA			, ,
No.25	610 308 8662	MOUNTING POWER BTM-M4KA			
No.26	610 308 8679	MOUNTING POWER TOP-M4KA			
No.27	610 308 8686	MOUNTING DUCT PWR BTM-M4K			
No.28	610 308 8693	MOUNTING DUCT PWR TOP-M4K			
No.29	610 308 8709	MOUNTING TEMP SW-M4KA			
No.30	610 308 8716	MOUNTING AC BTM-M4KA			
No.31	610 308 7054	OPTICAL BASE LMP-M4KA			
No.32	610 308 7061	OPTICAL BASE BTM-M4KA			
No.33	610 308 7078	OPTICAL BASE TOP-M4KA			
No.34	610 308 8136	COMPL, MOUNTING LNS-M4KA			
(SCREWS)					
No.40	411 025 5305	SCR S-TPG BIN 3X10			
No.41	411 026 8206	SCR S-TPG PAN 3X8			
No.42	411 001 9006				
No.43	412 067 5506				
No.44	411 030 5901				
No.45	411 181 4303				
No.46	411 025 5206				
No.47	411 025 6500				
No.48	412 058 5409				
No.49 No.50	411 142 3000 411 001 8702	SCR S-TPG BIN 3X16 SCR BIN 3X6			
No.50 No.51	411 001 8702	SCR FLT 3X6			
No.51	411 002 2709	SPECIAL SCREW			
No.52 No.53	412 063 7306				
No.54	411 023 4209				
110.34	111 001 0001	SCIU DIII 370			

Key No.	Part No.	Description	Key No.	Part No.	Description
ACCESS	ORIES				
△ AC COR	RD				
	(FOR US)				
		CORD, POWER-1.85MK, US			
	(FOR UK)				
		CORD, POWER-2.0MK			
	(FOR EU, ASIA,				
		CORD, POWER-2.0MK			
OWNER'S					
	(ENGLISH)				
		OWNER'S MANUAL-M4KA			
	(GERMAN)				
		OWNER'S MANUAL-M4KA-D			
	(FRENCH)	OWNER'S MANUAL-M4KA-F			
	(ITALIAN)	OWNER S MANUAL-M4RA-F			
		OWNER'S MANUAL-M4KA-I			
	(SPANISH)	ONLINE D THEOTHE TITLET I			
		OWNER'S MANUAL-M4KA-E			
RC TRANS	SMITTER (CXPF				
		ASSY, REMOCON CXPP			
		RC-BATTERY LID-CXKT			
OTHERS					
	645 056 0545	CABLE, VIDEO			



Schematic Diagrams Printed Wiring Board Drawings

Model Chassis No.
PLV-Z2 M4K-Z200


These schematic diagrams and printed wiring board drawings are part of the service manual original for chassis No. M4K-Z200, model PLV-Z2. File with the service manual No. SM5110585-00.

Note:

All the information of part numbers and values indicated on these diagrams are at the beginning of production. To improve the performance, there may be some differences to the actual set. When you order the service parts, use service parts code mentioned on the parts list in this service manual.

■ Parts description and reading in schematic diagram

- 1. The parts specification of resistors, capacitors and coils are expressed in designated code. Please check the parts description by the following code table.
- 2. Some of transistors and diodes are indicated in mark for the substitution of parts name. Please check the parts name by the following code table.
- 3. Voltages and waveforms were taken with a video color bar signal(1Vp-p at 75 ohms terminated) and controls to normal.
- 4. Voltages were taken with a high-impedance digital voltmeter.




Material table

Mark	Material
Е	Electrolytic
Р	Electrolytic (non-polarized)
С	Ceramic (temperature compensation)
K	Ceramic
F	Polyester
N	Polypropylene
М	Metalized polypropylene
Н	Metalized polypromylar
В	Ceramic (semiconductor)
G	Metalized polyestel
Υ	Composite film
S	Styrol
Т	Tantalum oxide solid electrolytic
U	Organic semiconductive electrolyte
D	Electric double layer electrolytic

Tolerance table

Mark	Tolerance				
Α	not specified				
В	±0.				
С	±0.	25			
D	±0.	5			
F	±1				
G	±2				
Е	±2.	5			
Н	±3				
J	±5				
K	± 0				
M	±20				
N	±30				
Р	+100	-0			
Q T	+30	-10			
	+50	-10			
U	+75	-10			
V	+20 -10				
W	+100 -10				
Х	+40 -20				
Υ	+150	-10			
Z	+80	-20			



Mark	Tolerance (nH)	Mark	Tolerance (%)
С	±0.25	G	±2
D	±0.5	J	±5
S	±0.3	K	±10
Α	±0.2	L	±15
		М	±20

Resistor Reading Example <u>1/2</u> <u>D</u> <u>J</u> <u>10K B</u> Characteristic <u>W</u> <u>K</u> Example Z (Carbon fuse) B (Non-burnable) Example 1/2 <u>C</u> K <u>1M</u> K indicates in K□ M indicate in M□ Resistance value Tolerance (see below table) Material (see below table)

Note: Resistor which is indicated with resistance value only are 1/6W carbon resistor. Resistor which is indicated with material, tolerance and value are 1/4W rated wattage.

Rated wattage (W)

Material table

Mark	Material
D	Carbon
N	Metal film
S	Oxide metal film
С	Solid
G	Metal glaze
W	Wire wounding or cement
Н	Ceramic
F	Fusible

Tolerance table

Mark	Tolerance
Α	±0.05
В	±0.1
С	±0.25
D	±0.5
F	±1
G	±2
J	±5
K	±10
М	±20
Р	+5 -15
Z	used in 0 ohm

Diode/Transistor Type Reading

Diode

Mai	Type number
R	1S2076A,1S2473,1N4148
AA	1S2076A,1S2473,1SS133,1N4148

Transistor

(1) NPN type


Mark	Type number						
	2SC536	2SC945A	2SC1815	2SC1740S			
AD	NF, NG	PA, QA	Y, GR	Q, R, S			
AE	NF, NG	PA, QA, RA	O, Y, GR	Q, R, S			


(2) PNP type


Mark		Type number						
	2SA608	2SA564A	2SA1015	2SA933S				
AB	NF	R	Y, GR	R				
AC	NF	Q, R	O, Y, GR	Q, R				


(3) Chip type

Mark	Type number				
	2SA1179/N	2SA1037K	2SA1037AK	2SC2812/N	2SC2412K
AJ	M6, M7	R, S	R, S		
AH				L6, L7	R, S











■ Printed Wiring Board Diagrams


R/C (SIDE:A)

R/C (SIDE:B)







AV (SIDE:A)




AV (SIDE:B)



LED (SIDE:A)



LED (SIDE:B)




⚠ CAUTION


This projector is isolated from AC line by using the internal converter transformer. Please pay attention to the following notes in servicing

- 1. Do not touch the part on hot side (primary circuit) or both parts on hot and cold sides (secondary circuit) at the same time.
- 2. Do not shorten the circuit between hot and cold sides.
- 3. The grounding lead must be connected to the ground of the same circuit when measuring of voltages and waveforms.

PCB_M4KA




A8 PCB_M4KA




PCB_M4KA


FILTER (SIDE:A)




FILTER (SIDE:B)




INLET (SIDE:A)




INLET (SIDE:B)




SENSOR (SIDE:A)




SENSOR (SIDE:B)




LAMP SW (SIDE:A)




LAMP SW (SIDE:B)



DOOR SW (SIDE:A)



DOOR SW (SIDE:B)



■ Pin description of diode, transistor and IC

